



KODEN

OPERATION MANUAL

COLOR ECHO SOUNDER

((Broadband)) ((DIGITAL))

CVS-1420

- This page intentionally left blank.-

**Declaration of Conformity**

**We, Koden Electronics Co., Ltd.; 5278 Uenohara, Uenohara-shi, Yamanashi-ken,
409-0112 Japan**

declare as manufacturer under our sole responsibility that the

Koden Echo Sounder CVS-1420

intended for use as a Marine Echo Sounder aboard vessels to which this declaration relates conforms to the following standards or other normative documents referring to EU directives and UK regulations

EU

Electromagnetic Compatibility Directive
2014/30/EU

EMC
IEC 60945 Ed.4.0 2002 (Clauses 9,10)

UK

Electromagnetic Compatibility
Regulations 2016 No.1091

EMC
IEC 60945 Ed.4.0 2002 (Clauses 9,10)

For assessment, see

- Test Report No. ES - 1090 E.M.C TEST REPORT No.SFF-012

RoHS conformity**EU**

RoHS Directive 2011/65/EU & (EU) 2015/863

UK

RoHS Regulations 2012 No.3032 [as amended]

Type names: CVS-1420

Consisting of: Display Unit: CVS-1420

Power Cable: CW-259-2M

- Software: Display Unit: CVS-1420 – Ver. xx.xx. bin (x used as wildcard)

Authorized representative:

Koden Elektronik GmbH

Am Gewerbepark 15, D-64823 Gross-Umstadt, Germany

Point of contact:


Koden Electronics Co., Ltd.

5278 Uenohara, Uenohara-shi, Yamanashi-ken, 409-0112 Japan

Mr. Jun Harayama, Manager, Quality Assurance Dept.

Tel.: +81 554 20 5860 Fax: +81 554 20 5875

Date: 18 August 2023


Jun Harayama

Manager / Quality Assurance Department

This certificate expires if new regulations come
in force or latest at 31 December 2027.

Document No. 83-2731U-X003

CVS-1420 Operation Manual
Doc No. 0093114215

Document Revision History

No.	Doc. No-Rev. No.	Date Revised (Y/M/D)	Revised Content
0	0093114215-00	2023/08/18	First edition
1	0093114215-01	2024/03/01	XID-adaptive TD Addition, Bottom Hardness Addition, TDM-031D/052A/062A/071/083/091D/ TD340-K/360-K/361-K/380-K Addition, Configuration of Equipment, All revision
2			
3			
4			
5			
6			
7			
8			
9			
10			

Document No. Revised Version Norm

When part of the document needs to be revised, the document has advanced revision number.

The document No. is indicated at the lower right side on the cover and at the left or right side of the footer region of each page.

© 2023-2024 Kodens Electronics Co., Ltd. All rights reserved.

No part of this publication may be reproduced, transmitted, translated in any form by any means without the written permission of Kodens Electronics Co., Ltd. The technical descriptions contained in this publication are subject to change without notice. Kodens assumes no responsibility for any errors, incidentals or consequential damages caused by misinterpretation of the descriptions contained in this publication.





Important Notice

- For copy and transcription of this Operation Manual (hereinafter referred to as this manual), permission from Kodon is needed. Kodon prohibits the un-authorized copy and transcription of this manual.
- If this manual is lost or damaged, consult a dealer of Kodon or Kodon.
- The specification of the products and the contents in this manual are subject to change without notice.
- The contents displayed on the menu of product may be different from the expression of this manual. The fonts and shapes of the keys and menus in the illustration may differ from the actual ones, and some parts may be omitted.
- Kodon is not liable for damages and troubles arisen from misunderstanding of the contents in this manual.
- Kodon is not liable for any damages caused by earthquake, lightning, wind and flood damage and fire for which Kodon is not responsible, and actions by third parties, other accidents, customer's unintended error/abuse and the use under other abnormal conditions.
- Kodon is not liable for damages of accompaniment (change/loss of memorized content, loss of business profit, stop of business) arisen from use or failure of our products.
- If the stored data are changed or lost, irrespective of causes of troubles and damages, Kodon is not liable for them.
- Kodon is not liable for any damages arisen from malfunction caused by combination of software and connected equipment in which Kodon is not engaged.




For Your Safe Operation




Pictorial used in this Operation Manual

This Operation Manual uses the following pictorials. Understand the meaning of each pictorial and implement the maintenance and inspection.







Symbol	Meaning
 Warning	Mark for warning This symbol denotes that there is a risk of death or serious injury when not dealing with it correctly.
	Mark for danger high voltage This symbol denotes that there is a risk of death or serious injury caused by electric shock when not dealing with it correctly.
 Caution	Mark for caution This symbol denotes that there is a risk of slight injury or damage of device when not dealing with it correctly.
	Mark for prohibition This symbol denotes prohibition of the specified conduct. Description of the prohibition is displayed near the mark.

Caution Item on Equipment

	Be careful of a high voltage inside. A high voltage, which may risk your life, is used. This high voltage remains in the circuit after you have powered off switch. To prevent touching the high voltage circuit inadvertently, the hard cover is provided to the high voltage circuit and the high voltage caution label is affixed. Ensure to power off switch for your safety and discharge the electricity remaining in the capacity before starting to check. An engineer authorized by our company should inspect and maintain
 Warning	Be sure to power off in the boat. If the power switch is inadvertently powered on during work, you will be electrified. To prevent such accident from occurring, ensure to power off in the boat and the power of equipment. Furthermore, it is safer to hang the caution tag described as [Under Work] near the power switch of equipment.
 Warning	Be careful of dust Inhaling dust may cause A respiratory disease. When cleaning the inside of equipment, be careful not to inhale dust. Wearing a safety mask is recommended.

 Caution	Caution on location of equipment Do not install the equipment where it is excessively damp and suffers from excessive water drops.
 Caution	Escaping from static electricity The static electricity may be generated from the carpet on the floor in the cabin or clothes made of synthetic fiber. The static electricity may destroy the electronic parts on the circuit board. Handle the circuit board, taking the measure of static electricity free.
 Caution	Install the transducer at the location where it is not affected by bubble and noise. The bubble and noise seriously degrade the performance of this unit.

Caution Item on Handling

 Warning	Do not disassemble or modify. It may lead to trouble, fire, smoking or electric shock. In case of trouble, contact our dealer or our company.
 Warning	In case of smoke or fire, boat power off and the power of this unit. It may cause fire, electric shock or damage.
	Be cautious of remaining high voltage. A high voltage may remain in the capacitor for several minutes after you have powered off. Before inspecting inside, wait at least 5 minutes after powering off or discharge the remaining electricity in an appropriate manner. Then, start the work.
 Caution	The information displayed in this unit is not provided directly for your navigation. For your navigation, be sure to see the specified material.
 Caution	Use the specified fuse. If un-specified fuse is used, it may cause a fire, smoke or damage.
 Caution	Whenever transmitting, be sure to submerge the transducer in water first. If transmitted without submerging the transducer, it may be damaged.

Contents

Document Revision History	i		
Important Notice	ii		
For Your Safe Operation	iii		
Contents	v		
Introduction	ix		
System Configuration	x		
Configuration of Equipment	xi		
Transducer and Frequency	xvi		
Chapter 1 Basic Operation	1-1		
1.1 How to use the key	1-1	1.7	Setting of Shift..... 1-9
1.2 Power On/Off	1-2		Setting of Manual Shift..... 1-9
Power on	1-2		Release of manual Shift..... 1-10
Forced execution	1-2		Setting of Auto Shift
Power off	1-3	1.8	Gain Adjustment..... 1-11
Alarm of Power Voltage	1-3		TVG..... 1-11
Temperature rise alarm of		1.9	Use of [EVENT] key
XID-adaptive TD	1-3		Selecting the event key
1.3 LCD Brilliance Adjustment	1-4		function
Adjustment of LCD Brilliance	1-4		Presetting the waypoint
Brightness Adjustment of Panel			Store the image..... 1-13
Brilliance	1-4		Fishing hot spot..... 1-13
1.4 Switch-over of Display mode	1-4	1.10	Use of [F1] / [F2] key..... 1-14
Normal Image (Low frequency,			Selecting the
High frequency).....	1-4		[F1] / [F2] key
Dual frequency.....	1-5		Preset of [F1] / [F2] key
Zoom (Low frequency,		1.11	Operation of VRM
High frequency).....	1-5	1.12	Display of fish information..... 1-15
Navigation Menu (NAV1, NAV2)	1-7		Display the fish symbol / Stop the
1.5 Selection of NAV Display	1-8		display of fish symbol..... 1-15
Type of NAV Display	1-8		Selecting the symbol info..... 1-16
Selection of NAV Menu	1-8		Fish symbol detection
1.6 Switch-over of Range	1-9		adjustment
Setting the range switching to			Size adjustment
auto range	1-9		Big fish / Big fish color
Setting the range switching to			Points to note in use of fish
Manual range	1-9		symbol..... 1-17
		Chapter 2	How to use the menu
		2.1	How to operate the menu
			Display the menu / Stop the
			display of menu..... 2-1
			Menu Operation
		2.2	Changing of Image Speed
		2.3	Rejection of Interference..... 2-2
			Interference Rejection..... 2-2
		2.4	Color Rejection of Weak Echo... 2-3

Color Rejection.....	2-3	Display Width	2-13
2.5 Rejection of Noise	2-3	Display the A scope / Stop the	
Noise Rejection	2-3	display of A scope	2-13
2.6 Setting of Shift step	2-3	Change the display color of echo	
2.7 Selection of Zoom	2-3	sounder image	2-14
2.8 Setting of Zoom Range	2-4	Change the depth value	2-14
2.9 Setting of Zoom Start	2-4	Display the depth unit / Stop the	
2.10 Preset of Range	2-4	display of depth unit	2-14
Easy registration method of the		Display the water temp graph /	
range	2-5	Stop the display of water temp	
2.11 Setting of Background Color	2-5	graph	2-14
2.12 Setting of White Line	2-5	Setting of the background color of	
2.13 Setting of Alarm	2-6	NAV display	2-14
Stopping the alarm sound	2-6	Setting of the echo sounder	
Setting the alarm	2-7	display at NAV display.....	2-14
Release the alarm	2-7	Image Swap	2-14
Confirm the alarm state.....	2-7	Display the Operation guide /	
2.14 Preset/ WPT edit/ WPT delete of		Stop the display of Operation	
Waypoint.....	2-8	guide.....	2-15
NAV Start.....	2-8	Display the detection area /	
Cancel the NAV	2-8	Stop the display of detection	
Edit the destination.....	2-8	area	2-15
Delete the waypoint.....	2-9	Setting of Scale display	2-15
All WPTs deletes	2-9	Change the scale value.....	2-15
Recall the stored image and		Change the image direction	2-15
preset it as a destination	2-9	Setting of Depth measurement	2-15
2.15 Store/Recall/Deletion of Image	2-10	Change the display color.....	2-16
Store the image.....	2-10	Setting of Key lock	2-16
Recall the stored image	2-10	Sub Depth Value	2-16
Delete the stored image	2-11	Change the User setting	2-16
All stored image deletes.....	2-11	Change the scale type	2-16
Add the comment to the stored		Change the bottom color.....	2-17
image.....	2-11	Change the image partition	2-17
2.16 Explanation of Menu Item	2-12	Selecting a display area of fish	
Inner-hull	2-12	symbol indication.....	2-17
Change the TX power	2-12	Display Bottom Hardness value	
Change the Pulse width	2-13	2-17
Change the Bandwidth.....	2-13		
D.Range	2-13		

Chapter 3 How to use the menu2	3-1	Past image	3-4
3.1 Display of Menu	3-1	Inner-hull	3-4
Display the menu	3-1	TD select (H) / (L)	3-5
Return to the normal menu	3-1	Ferrite.....	3-5
3.2 Setting of External Input/Output. 3-1		XID	3-5
Buzzer Setting.....	3-1	3.6 Setting of Adjust2 Item.....	3-5
Temp Source.....	3-1	STC strength adjust Low / High. 3-5	
Speed Source	3-1	STC depth adjust Low / High	3-5
Baud Rate	3-1	Color adjust.....	3-5
NMEA Monitor.....	3-2	Image speed adjust.....	3-6
NMEA Output Data	3-2	Bottom limit	3-6
External synchronous input	3-2	Sounding	3-6
Unreceived synchronization.....	3-2	BTMH adjust	3-6
3.3 Setting of Correction Item	3-3	3.7 Frequency Select.....	3-6
Draft Set.....	3-3	Frequency select (H) / (L)	3-6
Sonic Speed.....	3-3	Power frequency	
Water Temp.....	3-3	adjustment H / L.....	3-6
Boat Speed	3-3	Display the frequency / Stop the	
Directivity angle (Low/High)	3-3	display of frequency	3-6
Bubble	3-3	Chapter 4 Maintenance and Inspection ..	4-1
Bubble time set	3-3	4.1 Inspection.....	4-1
3.4 Setting of Basic Set Item	3-3	4.2 Cleaning.....	4-1
Language	3-3	Display unit	4-1
Range & Speed Unit.....	3-3	Transducer	4-1
Depth Unit	3-3	4.3 Fuse Replacement.....	4-2
Temperature Unit	3-4	4.4 If you suspect a trouble.....	4-2
Local time Offset.....	3-4	4.5 Diagnostic Test.....	4-3
GPS select	3-4	Diagnose	4-3
GPS initialize.....	3-4	Confirm the version.....	4-3
Bottom start.....	3-4	Return to the menu	4-3
Past image	3-4	Chapter 5 Installation	5-1
3.5 Maintenance Menu	3-4	5.1 Items of Caution on Installation .	5-1
Simulation	3-4	Unpacking the components	5-1
Slide show.....	3-4	Inspection of components and	
Initialize	3-4	accessories	5-1
System Check.....	3-4	Decision of Installing Location ...	5-1
All WPTs deletes	3-4	Laying and Connection of	
All stored image deletes	3-4	Cable.....	5-2
Bottom start.....	3-4		

Confirmation after Installation	5-2	XID-adaptive TD connection method	5-45
5.2 Installation of Display unit	5-3	TD340-K/360-K/361-K/380-K connection method	5-51
Desk-top Installation.....	5-3		
Flush-mount Installation	5-5		
5.3 Wiring	5-6	Chapter 6 Table Attached	6-1
Connection of Cable to Display unit.....	5-6	6.1 Menu List.....	6-1
Pin Assignment of Rear Connector	5-7	6.2 Specification	6-6
Connection of Power Cable	5-8	6.3 Dimensions	6-7
Connection with external echo sounder	5-9		
Connection with external navigation equipment	5-9		
Connection with Speed Sensor or Water Temperature Sensor	5-10		
Connection of External Monitor (J5)	5-11		
5.4 Serial Data.....	5-12		
Input Data	5-12		
Output Data	5-12		
5.5 Installation of Transducer	5-12		
Cautions on installation of transducer	5-13		
In case of Inner-hull.....	5-14		
In case of ship side installation	5-15		
In case of the ship's bottom installation	5-16		
Installation of TDM-052A/062A/083	5-17		
Installation of TDM-031D/071/091D	5-23		
Outline dimensions and specifications of transducers....	5-27		
5.6 Connection of Transducer	5-40		
Transducer connection to the connectors of Display unit.....	5-40		
Transducer connection method	5-40		

Introduction

The CVS-1420 Series is a Dual frequency Color LCD display echo sounder.


This unit equipped with digital process displays the circumstance in the water under all conditions, matching with the high luminance 10.4 inch LCD.

The main features of this unit are as follows:

- With the digital reception process, the compatibility of the high resolution in a shallow depth and the noise rejection capability in a deep depth are established. The auto mode function provides the best image.
- The high-performance LCD maintains high visibility under any conditions.
- The unit can be installed in an open bridge and is highly waterproof.
- Up to 10 images can be stored. If you connect the optional GPS, the fishing hot spot function, that directs your boat to navigate easily to the location desired, is available by marking the event mark when recalling the stored image.
- With the adoption of a specific filter (AR coat), an image can be seen clearly, refusing sunshine. The countermeasures against the reflection on the LCD screen and dew are provided. This display has a high level of visibility under all operation conditions.
- The various alarm functions are available. (Bottom, school of fish, water temperature*, board speed*, arrival*, XTE*, power) (Note: The mark * denotes that the connection of option is mandatory)
- When flush-mounting, the unit can be easily installed from front side.
- The RGB output for an external monitor is provided as standard equipment. The use of the external monitor enables you to observe easily the echo sounder screen at a location which is remote from a main unit. (External monitor: Prepared by a customer)
- Various transducers can be set by the menu. In addition, the frequency and transmission power can be set automatically.
- Compatible with fixed frequency transducer and broadband transducer with a transmission power of 1 kW to 3 kW.





System Configuration

Connection Diagram



Configuration of Equipment










Standard Equipment Configuration List


No	Name of item	Type	Remark	Weight/ Length	Quantity
1	Display unit 	CVS-1420	With mounting bracket and knob	7.8 kg	1
2	Hard cover 	A30MB10250		390 g	1
3	DC power cable 	CW-259-2M	With 3P connector and one end plain	2 m	1
4	Fuse 	F-7161-8A Cylinder (ø 6.4x30)	Normal fusion type for main power		1
5	Operation Manual	CVS-1420.OM.E	English		1
6	Quick Reference	CVS-1420.QR.E	English		1

Essential Option

No.	Name of item	Type	Remark	Weight/ Length	Quantity
1	Transducer	Refer to "Type of transducers"	With transducer cable		1
2	Cable for transducer	CW-836-3M	For 2kW to 3kW	3 m	1
3	Cable for transducer	CW-840-0.3M	For 1kW Needed when using the optional water temperature sensor / speed sensor	30 cm	1

Type of fixed frequency transducer








No.	Type	Frequency / Output	Material / Cable length / Cable diameter	Mounting method	Beam width (Right and left x back and forth) (-6dB)
1	TD-501C 	50/200 kHz 1 kW	Rubber mold 10m φ11	Inner-hull Ship's bottom/ Ship's side	50kHz 58°x20° 200kHz 17°x 6°
2	TD-501T-3B 	50/200 kHz 1 kW	Bronze 9m Φ5	Through hull	50kHz 20°x22° 200kHz 5°x 5°
3	TD-404T 	40kHz 3kW	Rubber mold 15m φ11	Ship's bottom/ Ship's side	40kHz 16°x11°
4	TD-504T 	50kHz 3kW	Rubber mold 15m φ11	Ship's bottom/ Ship's side	50kHz 14°x9°
5	TD-754 	75kHz 3kW	Rubber mold 15m φ11	Ship's bottom/ Ship's side	75kHz 14°x7°
6	TD-284A 	28kHz 3kW	Rubber mold 15m φ11	Ship's bottom/ Ship's side	28kHz 30°x18°
7	TD-504F 	50kHz 3kW	Rubber mold 15m φ11	Ship's bottom/ Ship's side	50kHz 14°x11°
8	150kHz 120φx1 	150kHz 2kW	Rubber mold 12m φ11	Ship's bottom/ Ship's side	150kHz 7°x7°
9	NGM100-200-12L 	200kHz 2kW	Rubber mold 12m φ11	Ship's bottom/ Ship's side	200kHz 6°x6°


10	TDM-031D 	50/200kHz 2kW	Rubber mold 15m φ11	Ship's bottom/ Ship's side	50kHz 27°x27° 200kHz 9°x9°
----	---	------------------	---------------------------	-------------------------------	-------------------------------



Caution: For Inner-hull installation, an Inner-hull kit is necessary.

Type of broadband transducer

No.	Type	Frequency	Material / Cable length / Cable diameter	Mounting method	Beam width (Right and left x back and forth) (-6dB)
1	TDM-052A 	38 to 75kHz 130 to 210kHz	Rubber mold 15m φ11	Ship's bottom	38kHz 27° x 14° 50kHz 20° x 12° 75kHz 14° x 7° 130kHz 11°x11° 170kHz 7°x7° 210kHz 6°x6°
2	TDM-062A 	38 to 75kHz 80 to 130kHz	Rubber mold 15m φ11	Ship's bottom	38kHz 27° x 14° 50kHz 20° x 12° 75kHz 14° x 7° 80kHz 18°x18° 100kHz 13°x13° 130kHz 11°x11°
3	TDM-071 	35 to 65kHz	Rubber mold 15m φ11	Ship's bottom/ Ship's side	35kHz 31°x 24° 65kHz 17°x13°
4	TDM-083 	28 to 60kHz 130 to 210kHz	Rubber mold 15m φ11	Ship's bottom	28kHz 31° x 15° 45kHz 18° x 10° 60kHz 12° x 7° 130kHz 11°x11° 170kHz 7°x7° 210kHz 6°x6°
5	TDM-091D 	42 to 65kHz 130 to 210kHz	Rubber mold 15m φ11	Ship's bottom/ Ship's side	42kHz 35°x35° 65kHz 22°x22° 130kHz 14°x14° 210kHz 8°x8°
6	TD340-K 	38 to 70kHz 130 to 220kHz	12m φ9	Ship's bottom/ Ship's side	38kHz 42° x 46° 50kHz 31°x31° 70kHz 21°x21° 130kHz 13°x13° 180kHz 9°x9° 220kHz 7°x7°
7	TD360-K TD361-K 	38 to 70kHz 130 to 220kHz	15m φ12	Ship's bottom/ Ship's side	38kHz 31° x 22° 50kHz 22° x 17° 70kHz 14° x 11° 130kHz 13° x 11° 180kHz 9° x 10° 220kHz 8°x8°

8	TD380-K 	38 to 70kHz 130 to 220kHz	15m $\phi 12$	Ship's bottom/ Ship's side	38kHz 23° x 16° 50kHz 17° x 12° 70kHz 13° x 9° 130kHz 13° x 11° 180kHz 9°x9° 220kHz 8° x 7°
---	--	------------------------------	------------------	-------------------------------	--



Caution: TDM-031D/052A/062A/071/083/091D (XID-adaptive TD^{*1}) must not transmit in the air, as it will be damaged.

^{*1} XID-adaptive TD: Transducer with a function to output internal information (internal temperature, element characteristics, etc.).

Option List

No	Name of Item	Specification	Remark	Weight/Length
1	Water temperature sensor/speed sensor	ST-80	For transom mounting Plastic made (with cable)	0.3 kg / 9 m
		ST-90	For through-hull mounting Plastic made (with cable)	0.6 kg / 9 m
		ST-100	For through-hull mounting Bronze made (with cable)	1.2 kg / 9 m
2	Water temperature sensor	TC02CS	For through-hull mounting	15m
		TC03-10	For transom mounting	10m
3	Kingston	TCK01	For TC02CS	
4	Inner-hull kit	MFB-04W	Plastic made for installing the transducer TD-501C	1.3 kg
5	Connecting cable	CW-372-5M	With 5P water resistant connector and one end plain	5m
		CW-373-5M	6P water resistant connectors at both ends	5m
		CW-374-5M	With 6P connector and 6P water resistant connector	5m
		CW-376-5M	With 6P water resistant connector and one end plain	5m
		CW-154A-5M	With 6P connector and one end plain	5m
		CW-844-3M	Needed when using the optional water temperature sensor / speed sensor	3m
6	Cable for external monitor	CW-576-0.5M	With 10P water resistant connector and D-Sub connector	0.5 m
7	Connector	BD-05BFFA-LL6001	5P water resistant connector	
		BD-06BFFA-LL6001	6P water resistant connector	
8	Junction Box	JB-34	Transducer junction box	0.58kg
9	Power rectifier	PS-010	Fuse (5A) 2 pcs.	
10	AC power cable	VV-2D8-3M	Both ends plain.	3 m
11	Transducer extension cable	C44-02		Specify length at order
12	Grounding cable	OW7/1.6S-3M		3 m
13	Transmission filter	C29EHB004A	Filter against leakage from wireless equipment	

Transducer and Frequency

The Display unit is used with the other transducer, please make sure to set the below items manually in line with the transducer installed.



Caution: Incorrect settings may damage the transducer.



Caution: There may be much noise on the screen even for the recommended power supply frequency depending on the transducer. In this case, set the power supply frequency to reduce the noise on the screen.

TD select (H), TD select (L)

When you turn on the power for the first time, set the language selection, inner hull selection, TD select (H), and TD select (L).



Caution: To connect the Transducer and the Display unit, select the transducer with TD selection (high) or TD selection (low), and then connect while the power is off.

- 1 Press the [MENU] key.
- 2 Select [Maintain] → [TD select (L)]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the transducer on the low frequency side. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key.
- 6 "Set ok?" is displayed. Select "Yes" to set.
- 7 Press the [MENU] key.
- 8 Set [TD select (H)] by referring to steps 2 to 7.
- 9 Long press the [BRILLÖ] key to turn off.
- 10 Connect the Transducer set in TD selection to the Display unit.
- 11 Press the [BRILLÖ] key to turn on the power.
- 12 Press the [F1] key and set [Image speed] to [Speed 5 1/1].
- 13 Press the [MENU] key. Then, the edit is finished.



Caution: When TD is selected, the frequency, power frequency, and beam angle change to the initial values of the Transducer.

If the TD on the low frequency side or high frequency side is not used, set the TD selection to "OFF".

When TD-284A or TD-504F is selected, check TD connection. If the TD connection cannot be confirmed, a TD unconnected error warning is displayed. If you get an alarm, check the TD connection.

When selecting the XID-adaptive TD, acquire XID data. If the XID data and selected TD are different, a "Forced execution" menu will be displayed. Please check that the TD connection and TD selection are correct.

The maximum transmission output is set for each type of TD.

Depending on the combination of TDs, sufficient transmission output may not be obtained.

Setting of Output Frequency

- 1 Press the [MENU] key.
- 2 Select [Freq] → [Freq select (L)]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Sets the output frequency on the low frequency side. (Press the [▲] key or [▼] key)
- 5 Set [Freq select (H)] by referring to steps 2 to 4.
- 6 Press the [MENU] key. Then, the edit is finished.

Setting of Power Frequency

- 1 Press the [MENU] key.
- 2 Select [Freq] → [Power freq adj L]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Sets the power supply frequency on the low frequency side. (Press the [▲] key or [▼] key)

The recommended power supply frequency (The factory set value:118.5kHz)

Output frequency	Recommended power frequency	Output frequency	Recommended power frequency
28kHz	118.5kHz	75kHz	103.5kHz
40kHz	123.0kHz	200kHz	108.7kHz
50kHz	103.5kHz	-	-



Caution: Even with the recommended power supply frequency, there may be a lot of noise depending on the Transducer. Set the power frequency to reduce noise on the screen.


- 5 Set [Power freq adj L] by referring to steps 2 to 4.
- 6 Press the [MENU] key. Then, the edit is finished.

Adjustment of bottom detection

When the bottom can't be detected or when the bottom is of mud pool or seaweed, [Gain (TD)] shall be turned up. When transfer to fish schools, etc. frequently occurs, [Gain (TD)] shall be turned down.

- 1 Press the [MENU] key.
- 2 Select [Adjust] → [Gain(TD)]. (See [2.1 How to operate the menu])
- 3 Press the [►] key. The image displays bottom only. It may show very strong fish targets.
- 4 Set a value to display the sea bottom continuously without interruption. For high frequency, turn [GAIN (HF) knob] and for low frequency, turn [GAIN (LF) knob]

After the alteration of setting, please confirm the condition for some time.
Those adjustments are recommended to be performed at the site of use.




- 5 Press the [MENU] key. Then, the edit is finished.

Chapter 1 Basic Operation


1.1 How to use the key

CVS-1420 Display unit



Various setting can be done directly. The menu list closes automatically after the key operation of the other keys than [menu].


No.	Key Name	Explanation
1	[F1]	Recalls directly the item preset.
2	[EVENT]	Notifies the external equipment of the present position. Presets the menu. It begins a fishing hot spot.
3	[Cursor] ▲▼◀▶	Selects the menu item. Changes the set value. Moves the VRM marker. IMoves the marker for notifying the event.Changes the shift.
4	[MENU]	Opens or closes the menu.
5	[F2]	Recalls directly the item preset.
6	[▲RANGE▼]	Changes the range setting.
7	[GAIN(HF) Knob]	Rotate: Changes the gain value. Press: Recalls the gain select.
8	[GAIN(LF) Knob]	Rotate: Changes the gain value. Press: Recalls the gain select.
9	[DISP]	Switches to the High frequency or Low frequency of echo sounder image, zoom and navigation menu.
10	[BRILL⏻]/ Power	Press: Power on. Adjusts the brilliance and brightness of panel. Long-press: Power off.



1.2 Power On/Off

Power on

- 1 Press the [BRILLÖ] key to power on. The startup menu is displayed. When started up, the internal memories (ROM, RAM) are automatically checked. When checking is normally finished, the menu below is displayed.



Caution: If an error occurs in the memory check, the LED on the operation panel blinks. The unit may be not function normally. If you suspect trouble, contact the dealer of your purchase or our company.

- 2 Language Selection at Initial Startup.

When powering on first, the [Language] menu is displayed.

Language
English
日本語

Select the language with [▲] key or [▼] key. (The language can be selected by rotating the [GAIN (HF) Knob] or [GAIN (LF) Knob].)

Caution: In addition to English, Japanese, there are several compatible languages.

- 3 When the installation of a transducer is [Inner-hull], select the [Yes].

Inner-hull
No
Yes

Press [▶] and [▼] keys in sequence, and select the [Yes].

- 4 Select the high frequency side transducer with "TD select (H)". Select the low frequency side transducer with "TD select (L)".

TD select (H)	TD select (L)
OFF	OFF
TDXXXX	TDXXXX

Press [▶] and [▼] keys in sequence, and select the Transducer.

- 5 After setting, press the [MENU] key.
- 6 Confirmation screen will appear. Select "Yes" to set. If you want to start over, select "No".

Set ok?
No
Yes

Press [▼] keys, and select the [Yes].

- 7 Press the [Menu] key to confirm each setting.
- 8 After a few seconds, the Echo sounder display will be appeared.

Forced execution

Select TDM-031D/052A/062A/071/083/091D and if there is an error, "Forced execution" menu will be displayed for confirmation.


Forced execution
No
Yes

Please check that the TD connection and TD selection are correct.

"Yes": Starts operation with the selected TD settings.

"No": [TD select (H)] / [TD select (L)] is set to OFF.

Explanation of the display:



Type of Gain

H: High frequency gain

L: Low frequency gain

Type of Range

R: M: Manual Range


R: A: Auto Range

R: AS: Auto Shift

Power off

- 1 When powering off, keep pressing the [BRILL] key for 3 seconds. The remaining time for the power to shut off is displayed on the menu.

Alarm of Power Voltage

If detecting the malfunction of the voltage, the  icon blinks and the alarm beeps.



Caution: In case of the low voltage or the high voltage, it shuts down. The precision of Power Voltage is ± 0.5 V.

Temperature rise alarm of XID-adaptive TD

TDM-052A/062A/083/091D measures the internal temperature of TD. Since these TDs may damage due to internal overheating, they automatically perform a protective operation. During protective operation, the transmission output will decrease and the feed speed will be delayed.

The protective operation starts when the "TD temperature rise" alarm occurs. The protective operation will stop when the internal temperature drops sufficiently.

1.3 LCD Brilliance Adjustment

Adjustment of LCD Brilliance

The brilliance of the display can be adjusted to facilitate visualization.

The [Lcd brill] and [Panel brill] can be switched every time when pressing the [BRILLÖ] key.

- 1 Press the [BRILLÖ] key for a short period of time to display the menu ([Lcd brill]).
- 2 Rotate the [GAIN (HF) Knob] or [GAIN (LF) Knob]. When "1" is selected, it is darkest. When "10" is selected, it is brightest.

Lcd brill
10

- 3 Press the [MENU] key to close the menu.

Brightness Adjustment of Panel Brilliance

The brightness of panel can be adjusted.

The [Lcd brill] and [Panel brill] can be switched every time when pressing the [BRILLÖ] key.

- 1 Press the [BRILLÖ] key for a short period of time to display the menu ([Panel brill]).
- 2 Rotate the [GAIN (HF) Knob] or [GAIN (LF) Knob]. When "1" is selected, it is darkest. When "10" is selected, it is brightest.

Panel brill
10

- 3 Press the [MENU] key to close the menu.

1.4 Switch-over of Display mode

7 kinds of displays are provided in all. Select the display suitable for your purpose.

- 1 Press the [DISP] key.
- 2 Select the display you desire to display.
(Press the [▲] key or [▼] key.)
(The set item can be selected by rotating the [GAIN (HF) Knob] or [GAIN (LF) Knob].)

Disp
NAV1
Normal (H)
Zoom (H)
Dual Freq
Zoom (L)
Normal (L)
NAV2

(H): High frequency

(L): Low frequency

NAV1: Navigation display1

NAV2: Navigation display2

- 3 Press the [MENU] key to close the menu.


Normal Image (Low frequency, High frequency)

Low frequency

Since the beam width is wide, the search range becomes wide so that the beam can search the deep depth.

High frequency


Since the beam width is narrow, it is hard to be interfered by noise and bubble in the sea so that the schools of fish can be searched in a high resolution.



Dual frequency

The High frequency image can be displayed in the right half side and the Low frequency image can be displayed in the left half side. Since the beam width differs depending on frequency, the schools of fish and sea bottom look different.

Caution: The low frequency screen can be displayed in the right half of the screen by replacing the screen and the high frequency screen is displayed in the left half. (See [2.16 Explanation of Menu Item, Image Swap])




Zoom (Low frequency, High frequency)

The normal image is displayed in the right half of the screen and the zoom image is displayed in the left half. A part of normal image can be zoomed. (1) [BTM.] (Bottom), (2) [B.D.] (Bottom Discrimination), (3) [Zoom], (4) [B.Z.] (Bottom Zoom) and (5) [B.F.Z.] (Bottom Follow Zoom) are provided for zoom.



The unit is set to (1) [BTM.] at ex-factory. To change to other zoom display, set it in the menu. (See [2.7 Selection of Zoom])

Caution: A right and left display can be switched. (See [2.16 Explanation of Menu Item, Image Swap])



Zoom type	Purpose	Zoom start position	Zoomed range
(1) Bottom	It is convenient to see the schools of fish near the bottom.	It displays the position of the bottom in the fixation in the display bottom part.	It displays the bottom and upper in the zoom.
(2) Bottom Discrimination	It is convenient to see the schools of fish and a bottom quality near the bottom.	It displays the position of the bottom in the fixation in the position of 1/4 under the display.	It displays the bottom and upper in the zoom, it displays under the bottom in the ordinary. (Under the bottom, it doesn't display in the zoom).
(3) Zoom	It is convenient to see the specified range in the zoom.	It displays a zoom start position in the fixation at the top of the display.	It displays in the zoom from the zoom start position to the range you set.
(4) Bottom Zoom	It is convenient to see the schools of fish near the bottom and the form of the bottom.	It displays the position of the bottom in the position which is the same as the ordinary display.	It displays upper side of the bottom in the zoom except the bottom.
(5) Bottom Follow Zoom	It is convenient to see the schools of fish near the bottom and the form of the bottom.	It always displays the position of the bottom in the lower part of the display.	It displays the bottom and upper and lower sides in the zoom.

(1) Bottom


The display width of zoom is displayed in orange.





**(2) Bottom Discrimination**

The display width of zoom is displayed in orange.

**(3) Zoom**



The display width of zoom is displayed in orange.



(4) Bottom Zoom**(5) Bottom Follow Zoom****Navigation Menu (NAV1, NAV2)**

The navigation menu can be displayed on the left side of the display. To display the information other than depth, sensors need to be connected. (See [1.5 Selection of NAV Display])

! Caution: Requires position data from GPS sensor.



1.5 Selection of NAV Display


Selection of NAV Display

The information can be displayed on the NAV display (NAV 1, NAV2).


Caution: Requires position data from GPS sensor.

Type of NAV Display


The following images can be displayed on the NAV Display (NAV1, NAV2).





Simple plotter



Compass



Speed meter




Wpt dist dir., Time required, Wind dir., Wind speed, depth, Lat/Lon, Boat speed, course, water temp, Heading and XTE

Selection of NAV Menu

- 1 Press the [DISP] key.
- 2 Select the [NAV1] or the [NAV2]. (Press the [▲] key or [▼] key)
- 3 [NAV1] is displayed at the right side.

Disp	NAV1
NAV1	Display1
Normal (H)	Display2
Zoom (H)	Display3
Dual freq	Display4
Zoom (L)	
Normal (L)	
NAV2	

- 4 Press the [▶] key.
- 5 Select either one of [Display1] to [Display4] by operating [▲] or [▼] key. At the locations where Display of NAV is shown, a numerical figure ①, ②, ③ or ④ is indicated. (The figure below is the case where [Display 1] is selected).



NAV1
Display1
Display2
Display3
Display4

Caution: When simple plotter, speed meter or compass is displayed on the screen, [Display2] and [Display4] cannot be selected.

- 6 Press the [▶] key.
- 7 Select the [Display1]. (Press the [▲] key or [▼] key.)

Display1
Simple plotter
Compass
Speed meter
Depth
Lat/Lon
Boat speed
Course

- 8 Press the [MENU] key to close the menu.

1.6 Switch-over of Range


The range of measured depth displayed on the display can be changed.

To meet your purpose, select the range of measured depth.

Setting the range switching to auto range

By following automatically the bottom, the image of echo sounder in the suitable range of measured depth can be displayed.

This mode is convenient to display always the range from sea level to bottom.



- 1 Press [▲] or [▼] key of [▲RANGE▼].
- 2 Select the [Auto Range]. (Press [▲] or [▼] key of [▲RANGE▼])

[▲] ↑	Range	↓ [▼]
	Auto range	
	5.0	
	10.0	
	20.0	
	50.0	
	100	
	160	
	300	
	500	
	Auto shift	

- 3 Press [MENU] to close the menu.
When [Auto Range] is set, the [R:A] is displayed at the upper side of menu.

Caution: Auto range will sound the range up to the [Sounding] setting. The maximum range is 2000 m. At the initial setup, the range is up to 1000 m. (See [3.6 Setting of Adujust2 Item, Sounding])

Setting the range switching to Manual range

The range can be manually selected:

- 1 Press [▲] or [▼] key of [▲RANGE▼].
- 2 Select the range you desire to set. (Press [▲] or [▼] key of [▲RANGE▼])

[▲] ↑	Range	↓ [▼]
	Auto range	
	5.0	
	10.0	
	20.0	
	50.0	
	100	
	160	
	300	
	500	
	Auto shift	

- 3 Press the [MENU] key to close the menu.
When the [Manual] is set, the [R: M] is displayed at the upper side of menu.

1.7 Setting of Shift

The [Shift] (Manual Shift) and [Auto Shift] are provided.

Manual Shift (Shift):

The image range is shifted up and down.
(Setting: m, fm, l.fm: 0 to 300, ft: 0 to 1000)

Caution: Only when the [shift] is registered in [F1] key or [F2] key, it is effective. It is invalid when not registered. (See [1.10 Use of [F1] / [F2] key])


Caution: When the equipment is shipped from the factory, the [shift] is registered in the [F2] key.

Auto Shift:

The image is automatically shifted so that the bottom is always displayed.

Setting of Manual Shift

The scope of range starting with the shift value is displayed.



- 1 Press [F2] key twice. The shift function is turned on.

Shift
OFF
ON

- 2 Press the [MENU] key to close the menu.
- 3 Press the [▲] key or [▼] key.
- 4 Change the set value of [Shift]. (Press the [▲] key or [▼] key)

Shift
10

- 5 Press the [MENU] key to close the menu.

Caution: This operation cannot be done while an auto range or auto shift is working.

Release of manual Shift

The shift function is released, and it returns it to former screen.

- 1 Press twice the [F2] key. The shift function is turned off.

Shift
OFF
ON

- 2 Press the [MENU] key to close the menu.

Setting of Auto Shift

The image is automatically shifted so that the bottom is always displayed.

- 1 Press [▲] of [▼] key of [▲RANGE▼].

- 2 Select the [Auto shift] (Press [▲] of [▼] key of [▲RANGE▼])

Range
Auto range
5.0
10.0
20.0
50.0
100
160
300
500
Auto shift

Range
40.0

- 3 Press the [▶] key.

Range
Auto range
5.0
10.0
20.0
50.0
100
160
300
500
Auto shift

Range
40.0


- 4 Select a range at [Auto shift]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu. When the [Auto shift] is set, the [R : AS] is displayed at the upper side of menu.

1.8 Gain Adjustment

When only the image of High frequency is displayed, the High frequency gain can be adjusted. (Setting: 0 to 10)

When only the image of Low frequency is displayed, the Low frequency gain can be adjusted.


Caution: If you increase the gain too much, noise will appear on the entire image, resulting in an unclear image. Adjust properly the gain so that the optimum image can be always displayed.



- 1 Turn [GAIN (HF) Knob] to display [Auto adjust high]. (The high frequency is explained below.)

Caution: The low frequency can be done by [GAIN (LF) Knob].

- 2 Adjust the gain by rotating the [Knob]. The [Cursor] key menu position can be moved.



Stop increasing of the gain just before noise appears on the image.

- 3 Every time when [GAIN (HF) Knob] is pressed, the [TVG] and [Gain (H)] are alternately displayed.
- 4 Press the [MENU] to close the menu.

The latest set value of frequency (High frequency or Low frequency) adjusted is displayed at the upper left side of menu.

Example:

The High frequency gain is 8.0 → H: 8.0.

H: 8.0	R: M	12.6 V
--------	------	--------

TVG

The TVG adjusts the difference of strength between echoes reflected from the shallower depth and echoes reflected from deeper depth so that the reflection can be uniformed.

The deeper the depth is, the reflected signal of echo sounder becomes weaker due to attenuation. Thus, comparing the signal reflected from the fish of the same size, the signal reflected from the fish in the shallower depth is stronger than that in the deeper depth.

The TVG adjusts the echo signal reflected from the shallower depth to be equal to that reflected from deeper depth by decreasing the receiver gain so that the effect that the strength of echo signal reflected from the shallower depth looks the same as that reflected from the deeper depth provided.

[STC depth H] adjusts the effect of high frequency TVG. [STC depth L] adjusts the effect of low frequency TVG. [High Sensitivity] can adjust the effect of TVG, making it easy to see the image of the fish. [Based on Seabed] adjusts the effect of TVG and makes the image of the seabed the same sensitivity at any depth.

- 1 Press twice the [GAIN (HF) Knob].
- 2 Select the [STC depth H], [STC depth L], [High Sensitivity], [Based on Seabed]. (Press the [▲] key or [▼] key)

TVG
STC depth H
STC depth L
High Sensitivity
Based on Seabed

- 3 Press the [MENU] key to close the menu.

1.9 Use of [EVENT] key

By pressing the [EVENT] key, three functions of [Store Position], [Store Image] and [Fishing hot spot] are available.

The fishing hot spot is the function to instruct your boat to navigate easily to a point where you desire to go back.

[Store pos]: The latitude and longitude of a point can be stored in the destination list.

[Store image]: An image of the echo sounder can

be stored in the internal memory.

[Fishing hot spot]: The WPT navigation starts, using the latitude and longitude of a point which is set as a destination by pressing the [EVENT] key. Simultaneously, the latitude and longitude of the point can be stored in the destination list.

Caution: Requires position data from GPS sensor.

Selecting the event key function

Select the functions when pressing the [EVENT] key.

- 1 Press the [MENU] key.
- 2 Select [System] → [EVENT Key set]. (Press the [▶] key or [▲] key or [▼] key) (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Change the setting of [EVENT key set]. (Press the [▲] key or [▼] key)

EVENT key set
Store pos
Store image
Fishing hot spot


- 5 Press the [MENU] to close the menu.

Presetting the waypoint

When you find the school of fish or tide, its location can be preset as a waypoint. (10 locations at maximum)



When presetting the waypoint, switch [System] → [EVENT Key set] → [Store pos]. (See [1.9 Use of [EVENT] key Selecting the event key function])

- 1 In the state that no other key is pressed, press the [◀] key or [▶] key.
- 2 Move the cursor (red line) with the [◀] key or [▶] key to the location to be preset as a waypoint.



Cursor (Red line)

- 3 Press the [EVENT] key. When decided, the red line is drawn at the designated location on the echo sounder menu and the latitude and longitude of designated location are registered in the waypoint list. At this moment, the list number of preset waypoint is displayed.



- 4 After a certain time passes, the message disappears and presetting the waypoint is finished.

! Caution: When pressing the [EVENT] key, if [In out] → [NMEA output data] → [TLL] is set to ON, the latitude and longitude of location above-designated is output to the navigation system connected.

! Caution: If the waypoint list is full, the preset destination list is not deleted, showing the message that the list is fully filled. After a certain time passes, the message disappears.

A waypoint list is full.
Registration is not completed

! Caution: If the waypoint list is full, delete an unnecessary waypoint from the waypoint list.

Store the image

When you find the schools of fish, its location can be stored as a waypoint.
(10 locations at maximum)

When storing the image, switch [NAV] → [EVENT Key set] → [Store pos]. (See [1.9 Use of [EVENT] key Selecting the event key function].)

1 Press the [EVENT] key.

Processing is displayed.

2 After a certain time passes, the image of echo sounder presently displayed is stored and the list number of stored image is displayed.

Image data list # 1 is registered

3 After a certain time passes, the message disappears and storing the image is finished.

! Caution: If the waypoint list is fully filled, the preset destination list is not deleted, showing the message that the image is fully filled. After a certain time passes, the message disappears.

A list of Pic is full.
Registration is not completed.


As for deletion and recall of images, see [2.15 Store/Recall/Deletion of image].

Fishing hot spot


Leads you back to your favorite fishing hot spots or other previously stored positions in memory with input from optional GPS sensor. (See [2.14 Preset/ WPT edit/ WPT delete of Waypoint])

To perform the fishing hot spot, it is necessary to select [System] → [EVENT key set] → [Fishing hot spot]. (See [1.9 Use of [EVENT] key Selecting the event key function].)

- 1** In the state that no other key is pressed, press the [◀] key or the [▶] key.
- 2** Move the cursor (red line) to a point you desire to go back with the [◀] key or [▶] key.



- 3** Press the [EVENT] key. When you decide, the red line is drawn on the image of the echo sounder at the point you designate and the latitude and longitude of the point you designate is stored in the destination list. At this moment, the number of the stored destination list is displayed.
- 4** The navigation display (NAV1) is displayed and the WPT navigation starts.



Note: The display of NAV1 is displayed.

- 5 To stop the fishing hot spot, cancel destination navigation. (See: [2.14 Preset/ WPT edit/ WPT delete of Waypoint], [Cancel the NAV].)

1.10 Use of [F1] / [F2] key

At ex-factory, the [Image Speed] is assigned to the [F1] key, and the [Shift] is assigned to the [F2] key. The function settable to the [F1]/[F2] key can be selected among [Image Speed], [IR], [Color Rejection], [Noise Rejection], [Shift], [Zoom Range], [Zoom Start], [A scope], [White line], [Background color], [Disp width], [Nav start], [NAV1], [NAV2], [Image swap], [Image recall], [Sona-tone] and [User set]. Set the function frequently used for your convenience.

Selecting the [F1]/[F2] key

- 1 Press the [F1] key or [F2] key.
- 2 Select the setting with [▲] key or [▼] key.

Example [Image speed]

Image speed
Speed1
Speed2
Speed3
Speed4
Stop
Speed5 (1/1)
Speed6
Speed7
Speed8
Speed9

Caution: When the fish symbol function is made effective, the image speed becomes two kinds ([Speed5 (1/1)] or [Stop]).

- 3 Press the [MENU] key to close the menu.

Preset of [F1] / [F2] key

- 1 Press the [MENU] key.
- 2 Select [System] → [F1 key set] or [F2 key set]. (Press the [▶] key or [▲] key or [▼] key.) (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the function. (Press the [▲] key or [▼] key)

F1 key set
Image
IR
Color Rejection
Noise Rejection
Shif
Zoom Range
Zoom
A scope
White line
Background Color

- 5 Press the [MENU] key to close the menu. The icons of functions preset are displayed at the upper right side on the menu.

	← Image speed		← Image recall
	← IR		← Image swap
	← Color rejection		← NAV1
	← Noise rejection		← NAV2
	← Shift		← Disp width
	← Zoom Range		← User set
	← Zoom		
	← A scope		
	← White Line		
	← Background color		


Other than the above operation method. When keep pressing the [F1] key or [F2] key for few second, the key set menu is displayed.

1.11 Operation of VRM

The VRM (movable marker) shown by the green line can be moved up and down.

It is convenient to measure the depth by aligning with the target such as school of fish.

- 1 In the state that no other key is pressed, press the [▲] key or [▼] key. The movable marker (straight line) is displayed.
- 2 Press the [▲] key or [▼] key. The movable marker moves up and down. The movable marker and the numerical of marker depth are simultaneously highlighted.



When displaying dual images, if the [◀] key or [▶] key is pressed, the movable marker moves to the neighboring image.

- ⚠ **Caution:** When several seconds pass after finishing the VRM operation, the numerical of marker depth becomes normal display.
- ⚠ **Caution:** If VRM is moved to the top of the display, the VRM can be disappeared.
- ⚠ **Caution:** VRM can be operated by turning [GAIN (LF) Knob] at the high frequency screen.
- ⚠ **Caution:** VRM can be operated by turning [GAIN (HF) Knob] at the low frequency screen.

1.12 Display of fish information

When transducer TD-501C is connected, specific response can be displayed as [Fish symbol].

For detection of fish information, 2 frequencies, 200 kHz and 50 kHz are used.


Only in case echo comes up in both frequencies, the detection can be made.

By [Symbol info], the magnitude and the value of depth of the response can be displayed.


- ⚠ **Caution:** Fish information is to display the specific responses in an easy way to watch. Displays of [Fish symbol] do not always mean that there is fish there.
- ⚠ **Caution:** The area where [Fish symbol] can be displayed is from 3 m to 100 m. (ft: 10 to 330, fm: 2 to 54, l.fm: 2 to 60)
- ⚠ **Caution:** [Fish symbol] is not displayed in the range that is deeper than 120m. (ft: 350, fm: 60, l.fm: 70)
- ⚠ **Caution:** When the fish symbol function is made effective, the image speed becomes 2 kinds ([Speed5 (1/1)] or [Stop]).
- ⚠ **Caution:** Adjustment is necessary when equipped with Inner-hull. (See [2.16 Explanation of Menu Item, Inner-hull].)
- ⚠ **Caution:** When this function is made effective, the setting of [Pulse width] and [Band width] becomes invalid.


Display the fish symbol/Stop the display of fish symbol

- 1 Press the [MENU] key.
- 2 Select [Display1] → [Fish symbol]. (Press the [▶] key or [▲] key or [▼] key.) (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the symbol to be displayed on the screen. (Press the [▲] key or [▼] key)



- 5 Press the [MENU] key to close the menu.

When this function is effective, the icon  is displayed at the top of the screen.


 **Caution:** When [Fish symbol] on the screen does not always mean that the response shows fish.

Selecting the symbol info


[Symbol info] is effective only when [Fish symbol] is displayed.


- 1 Press the [MENU] key.
- 2 Select [Display1] → [Symbol info]. (Press the [▶] key or [▲] key or [▼] key.) (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the information associated with [Fish symbol] (Press the [▲] key or [▼] key.)


Symbol info
OFF
Depth
Size
Bottom↔Fish

 **Caution:** The display of [Size] is expressed in cm.

- 5 Press the [MENU] key to close the menu.

 **Caution:** The magnitude by [Symbol info] would not be always the response from fish. And it may be incorrect due to various environmental conditions. Please take these as reference.

 **Caution:** The value of depth by [Symbol info] would not be always the response from fish. That shows the point that there was specific response.


 **Caution:** Please correct the size when the indicated value is different from the fish that actually fished.


Fish symbol detection adjustment

Detection of fish marks can be adjusted.

Select [Correct] → [Detect adjust f].

Fish marks are hardly displayed. (Error in detection is less) ← 1 2 3 4 5 6 → Fish marks are easily displayed. (More possible false detections)

 **Caution:** If the larger the set values become, the more fish marks can be displayed with more false detections.

 **Caution:** For Through-hull installation, adjust between 1 and 4. For Inner-hull installations, adjust between 3 and 6.

Size adjustment


The indicated size of fish marks can be adjusted.

Please correct the size when the indicated value is different from the fish that actually caught.

Select [Correct] → [Size adjust].

Values of indicated size will be decreased. ← 1 2 3 4 5 6 7 8 9 10 → Values of indicated size will be increased.

The indicated size will change by approximately 10 to 20 percent of the value, per one setting value.

 **Caution:** When the value of [Detect adjust f] is set at 5 or 6, the size of fish can not be specified and there may be cases where no numerical figures are displayed or only "----" is displayed. When there is no display of numerical figures, it is judged that fish are too small. When "----" is displayed, it is judged that fish is too big.

Big fish / Big fish color

The fish bigger than the set value [cm] is specified as big fish.

Select keys of [Display2] → [Big fish].

Colors for values of big fish can be assigned.

Select keys of [Display2] → [Color table 2] → [Big fish color].

Points to note in use of fish symbol

The values displayed by this function may be incorrect depending on various environmental conditions. In use of these values, please understand the following factors of error, and use them as reference:

[Factors of error]

- 1** When there are overlapping responses, all of them may be displayed to show the magnitude of a point.
- 2** The strength of reflection may depend on the output of transducer unit and may result in a factor of error.
- 3** The strength of reflection may depend on the kind of fish and may result in a factor of error. As for the fish such as the squid which don't have an air bladder, the error is big.
- 4** Fish banks, fishing net, fishing equipment, air bubbles and floating objects, etc. may be detected and displayed.
- 5** When the transducer unit is mounted in inner-hull, there may be cases where response cannot be detected depending on attenuation, and large error may be generated.
- 6** The strength of reflection may depend on the difference of ship handling such as stoppage and cruising, and may result in a factor of error.
- 7** Each transducer unit may have difference in transmission/receiving performance to cause error.
- 8** When there is dirt in the sea and the plankton layers have been generated, it becomes the factor of the error margin.

- This page intentionally left blank.-


Chapter 2 How to use the menu

2.1 How to operate the menu

Display the menu / Stop the display of menu

- 1 Press the [MENU] key.
The menu and explanation of operation are displayed.

Name of menu selected Menu column	Setting item Setting item column	Setting value Setting value column
Adjust	Image speed	Speed 5
D.range	IR	Stron
Display1	Color rejection	0%
Display2	Noise rejection	0
Alarm1	TX power	Auto
Alarm2	Gain (TD)	
NAV	Pulse width	Middle
Image	Band width	Middle
System	D.Range	24dB
Freq	Return	
Next		



It is displayed when the [Operation Guide] is set to ON.

(See [2.16 Explanation of Menu Item Display the operation guide / Stop the display of operation guide].)

- 2 Press the [MENU] key.
The menu and explanation of operation close.

Menu Operation

- 1 When the menu is displayed, press the [▲] key or [▼] key to select the menu name. Depending on the selected menu name, the content in the set item column at the right side changes. (The menu name can be selected by rotating the [GAIN (HF) Knob] or [GAIN (LF) Knob].)

Adjust	Shift step	1m
D.range	Zoom type	BTM.
Display1	Zoom range	10.0m
Display2	Zoom start	0m
Alarm1	Disp width	Center
Alarm2	Range preset	
NAV	Return	
Image		
System		
Freq		
Next		

- 2 Press the [▶] key.
The cursor appears in the set item column. (The cursor appears by pressing the [GAIN (HF) Knob] or [GAIN (LF) Knob].)
- 3 Select the set item you desire to change with the [▲] key or [▼] key. (The set item can be selected by rotating the [GAIN (HF) Knob] or [GAIN (LF) Knob].)

Adjust	Shift step	1m
D.range	Zoom type	BTM.
Display1	Zoom range	10.0m
Display2	Zoom start	0m
Alarm1	Disp width	Center
Alarm2	Range preset	
NAV	Return	
Image		
System		
Freq		
Next		

- 4 Press the [▶] key.
The set menu corresponding to the selected item is displayed. (It can be displayed by rotating the [GAIN (HF) Knob] or [GAIN (LF) Knob].)

Zoom range
10.0
m

- 5 Change the set content with the [▲] key or [▼] key. (It can be changed by rotating the [GAIN (HF) Knob] or [GAIN (LF) Knob].)
- 6 Press the [◀] key.
The cursor returns to the set item column. (It can be returned by rotating the [GAIN (HF) Knob] or [GAIN (LF) Knob].)

- 7 To select the other menu name item, press the [◀] key.
The cursor returns to the menu column.
- 8 Press the [MENU] key to close the menu.

2.2 Changing of Image Speed

The image speed of echo sounder can be changed. Even if the schools of fish and bottom are same, the image changes depending on the image speed.

The image speed becomes slow in the order of [Speed1] → [Speed2] → → [Speed9].
When [stop] is selected, the image stops.

! Caution: When the fish symbol function is made effective, the image speed becomes 2 kinds ([Speed5 (1/1)] or [Stop]).

- 1 Press the [MENU] key.
- 2 Select the [Adjust] → [Image Speed]. (See [2.1 How to operate the menu].)
- 3 Press the [▶] key.
- 4 Change the setting of [Image Speed]. (Press the [▲] key or [▼] key.)

Image speed
Speed 1
Speed 2
Speed 3
Speed 4
Stop
Speed 5 (1/1)
Speed 6
Speed 7
Speed 8
Speed 9

- 5 Press the [MENU] key to close the menu.


2.3 Rejection of Interference

Interference Rejection

The interference noise from the echo sounder of other boats can be reduced.

If a neighboring boat uses the echo sounder having the same frequency and pulse transmission rate as those your boat has, the interference noise may be displayed. If you set the interference rejection, the interference noise can be reduced. In the order of weak → strong, the noise rejection capability becomes high.

The difference of images based on the different settings of [Interference reduction]



- 1 Press the [MENU] key.
- 2 Select the [Adjust] → [Interference Rejection]. (See [2.1 How to operate the menu].)
- 3 Press the [▶] key.
- 4 Change the setting of [Interference Rejection]. (Press the [▲] key or [▼] key.)

IR
OFF
Weak
Strong

- 5 Press the [MENU] key to close the menu.


2.4 Color Rejection of Weak Echo

Color Rejection

The color of weak echo can be rejected.

Rejecting noise on the entire image and weak echo around the school of fish makes it easier to see the school of fish. It is the convenient function when displaying the echo stronger than the specific signal. (Setting: 0 ~ 50 %)

- 1 Press the [MENU] key.
- 2 Select the [Adjust] → [Color Rejection]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Change the setting of [Color Rejection]. (Press the [▲] key or [▼] key.)



- 5 Press the [MENU] key to close the menu.

2.5 Rejection of Noise


Noise Rejection

The influence of noise can be reduced.

Due to echo reflected from plankton and trash, the speck-like noise may appear on the entire image. Setting the [Noise rejection] reduces the speck-like noise and makes it easier to see the image of school of fish. (Setting: 0 ~ 10)

The greater the set value becomes, the stronger the effect of noise rejection becomes.

- 1 Press the [MENU] key.
- 2 Select [Adjust] → [Noise rejection]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Change the setting of [Noise rejection]. (Press the [▲] key or [▼] key)



- 5 Press the [MENU] key to close the menu.

2.6 Setting of Shift step

The shifting range is set by pressing the [▲] key or [▼] key one time. (Setting range: 1m, 10m, 1/8, 1/4)

- 1 Press the [MENU] key.
- 2 Select the [D.range] → [Shift step]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Change the setting of [Shift step]. (Press the [▲] key or [▼] key.)

Shift step
1m
10m
1/8
1/4

- 5 Press the [MENU] key to close the menu.

Caution: When the shift is set to 1/4 with 100m range, it shifts by 25m.

2.7 Selection of Zoom

Set the zoom display with the display mode ([zoom (H)] or [zoom (L)]).

The [Bottom], [Bottom Discrimination], [Zoom], [[Bottom Zoom] and [Bottom Follow Zoom] are provided. (See [1.4 Switch-over of Display mode])

- 1 Press the [MENU] key.
- 2 Select [D.range] → [Zoom type]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the zoom type. (Press the [▲] key or [▼] key)

Zoom type
BTM.
B.D.
Zoom
B.Z.
B.F.Z.

5 Press the [MENU] key to close the menu.

For each zoom display, refer to [1.4 Switch-over of Display mode].


2.8 Setting of Zoom Range

Set the zoom range in each mode of [BTM], [Bottom Discrimination], [Zoom], [Bottom Zoom] and [Bottom Follow Zoom]

The zoom range of each mode is identical.

(See [1.4 Switch-over of Display mode])

(Setting: m: 2.5 to 200, fm, l.fm: 2.5 to 150, ft: 10.0 to 650)



- 1 Press the [MENU] key.
- 2 Select [D. Range] → [Zoom range]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Change the set value of [Zoom range]. (Press the [▲] key or [▼] key)

Zoom Range
10.0
m


5 Press the [MENU] key to close the menu.

2.9 Setting of Zoom Start

Select the zoom start in the [Zoom].

(See [1.4 Switch - over of Display mode])

(Setting: m: 0 to 2000, fm, l.fm: 0 to 1100, ft: 0 to 6000)



- 1 Press the [MENU] key
- 2 Select [D. range] → [Zoom start] (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Change the set value of [Zoom start]. (Press the [▲] key or [▼] key)

Zoom start
10
0-800 m

5 Press the [MENU] to close the menu.

2.10 Preset of Range

The range switched with the [▲RANGE▼] key can be set.

Preset the set value suitable for you purpose.

(Setting range: m: 2.5 to 2000, fm, l.fm: 2.5 to 1100, ft: 10 to 6000)

- 1 Press the [MENU] key.
- 2 Select [D.range] → [Range preset] → [Range 1 to 8]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.

- 4 Select [Range 1 to 8]. (Press the [▲] key or [▼] key)

Adjust	Prev	
D.range	Range 1	5.0 m
Disp1	Range 2	10.0 m
Disp2	Range 3	20.0 m
Alarm1	Range 4	50.0 m
Alarm2	Range 5	100 m
NAV	Range 6	160 m
Image	Range 7	300 m
System	Range 8	500 m
Freq	Return	
Next		

Caution: Select [Forward], and press [▶] key to return to the previous menu.

- 5 Press the [▶] key.
6 Select the set value of [Range 1 to 8]. (Press the [▲] key or [▼] key)

Range1
20.0
m

- 7 Press the [MENU] key to close the menu.

Easy registration method of the range

- 1 Press [▲] or [▼] key of [▲RANGE▼].
2 Change the range you desire to set. (Press [▲] or [▼] key of [▲RANGE▼])

	Range
[▲]	Auto range
↑	5.0
	10.0
	20.0
	50.0
	100
	160
	300
	500
	Auto shift
	↓ [▼]

- 3 Press the [▶] key.
4 Select the set value of Range. (Press the [▲] key or [▼] key)

Range1
5.0
m

- 5 When the [◀] key is pressed, it returns to the [range]. Other detecting range can be continuously changed.
6 Press the [MENU] key to close the menu.

2.11 Setting of Background Color

Responding to the ambient brightness, the background color of display can be changed.


- 1 Press the [MENU] key.
2 Select [Display1] → [Background color]. (See [2.1 How to operate the menu])
3 Press the [▶] key.
4 Change the setting of [Background color]. (Press the [▲] key or [▼] key)

Background color
Pale blue
Marine blue
Blue
Dark blue
Black
Darkkhaki
Mediumseagreen
Light grey
White
Night mode

- 5 Press the [MENU] to close the menu.

2.12 Setting of White Line

As the surface of bottom is marked with the white line of constant width, the school of fish at the bottom can be easily identified.



- 1 Press the [MENU] key
- 2 Select [Display1] → [White line]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Change the setting of [White line].
 “1” is narrowest. “5” is widest.
 In the auto mode, responding to the strength of echo reflected from the bottom, the width of white line changes. (Press the [▲] key or [▼] key)

White line
OFF
1
2
3
4
5
Auto

- 5 Press the [MENU] key to close the menu.

2.13 Setting of Alarm

6 alarms of bottom alarm, fish alarm, water temp alarm, speed alarm, arrival alarm and XTE alarm can be set.

They are notified by alarm sound and alarm display.

[Bottom alarm] issues the alarm when the position recognized as the bottom is shallower than the upper limit or deeper than the lower limit. It is convenient when keeping the specific depth. (Setting: m: 0 to 2000, fm, l.fm: 0 to 1100, ft: 0 to 6000)

[Fish alarm] issues the alarm when an echo recognized as school of fish exists in the set

range. It is convenient for you to judge whether the echo of school of fish is present or not.

(Setting: m: 0 to 2000, fm, l.fm: 0 to 1100, ft: 0 to 6000)

Caution: In the [Level], select the strength of echo reflected from the schools of fish in the [Fish alarm].

[Water temp alarm] issues when the water temp is within or out of the set range. It is convenient to keep the specific water temp region. (Setting: - 5 to 45 °C, 23 to 113 °F)

[Speed alarm] issues when the boat speed is faster or slower than the set range. It is convenient when the speed limit is obliged. (Setting: 0 to 80 kn, 0 to 148 km/h)

[Arrival alarm] can be used in the state that the destination is set. The alarm is issued when your boat arrives within a certain range of destination. A certain range is set in the [NAV alarm range]. (See [1.9 Use of [EVENT] key].)

[XTE alarm] can be used in the state that the destination is set. The alarm is issued when your boat is off a certain distance from the course on the line drawn straightly from destination to the location when setting the destination. A certain distance is set in the [NAV alarm range].

Caution: In the [NAV alarm range], select the alarm range of [Arrival alarm] and [XTE alarm]. (Setting: 5 to 999 m)

Caution: The setting range of [Arrival alarm] and [XTE alarm] can not be separately set.

Stopping the alarm sound

To stop the alarm sound and the alarm display, press [MENU] key.

Setting the alarm

Adjust	Bottom alarm	OFF
D.range	Upper depth	5m
Disp1	Lower depth	50m
Disp2	Fish alarm	OFF
Alarm1	Position	5m
Alarm2	Range	50m
NAV	Level	Medium
Image	Return	
System		
Freq		
Next		

Adjust	Water temp alarm	OFF
D.range	Upper temp alarm	20.0 °C
Disp1	Lower temp alarm	15.0 °C
Disp2	Speed alarm	OFF
Alarm1	Speed limit	0kn
Alarm2	Arrival alarm	OFF
NAV	XTE alarm	OFF
Image	NAV alarm range	10m
System	Return	
Freq		
Next		

- 1 Press the [MENU] key.
- 2 Select your desired alarm from [Alarm 1] or [Alarm 2]. (See [2.1 How to operate the menu].)
- 3 Press the [▶] key.
- 4 Select the [ON] of alarm you desire. (Press the [▲] key or [▼] key)
- 5 If the setting of [Alarm range] is provided in the alarm desired, select the alarm range. (See [2.1 How to operate the menu])
- 6 Change the set value of alarm range. (Press the [▲] key or [▼] key)
- 7 Press the [MENU] key to close the menu.


Release the alarm

- 1 Press the [MENU] key.
- 2 Select the alarm to be released from [Alarm 1] or [Alarm 2]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [OFF] of alarm to be released. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Confirm the alarm state

The set state of [Bottom alarm] and [Fish alarm] can be confirmed on the bar at the right corner of display. However, when the display is out of the range, they are not displayed.

When [Water temp alarm], [Speed alarm], [Arrival alarm] or [EXT alarm] is ON, the corresponding icon is displayed at the upper side of the screen.



2.14 Preset/WPT edit/WPT delete of Waypoint

NAV Start

The NAV can be started by selecting the destination from the destination list.

To perform the NAV start, the destination must be preset. (See [1.9 Use of [EVENT] key])

Caution: Requires position data from GPS sensor.

- 1 Press the [MENU] key.
- 2 Select [NAV] → [NAV start]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Destination list] preset. (Press the [▲] key or [▼] key)

NAV start			
No.	Comment	Lat	Lon
1	WPT00001	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
2	WPT00002	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
3	WPT00003	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
4	WPT00004	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
5	WPT00005	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
6	WPT00006	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
7	WPT00007	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
8	WPT00008	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
9	WPT00009	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
10	WPT00010	XX° XXXX.XXXXN	XXX° XXXX.XXXX E

Caution: The list No. selected is reversed in red.

- 5 Press the [▶] key.
- 6 Select the [Yes] in the confirmation menu. (Press the [▲] key or [▼] key)

NAV starts
Yes
No

- 7 Press the [MENU] key. Then, the NAV starts.

Cancel the NAV

The NAV started can be cancelled halfway.

- 1 Press the [MENU] key
- 2 Select [NAV] → [NAV cancel]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Press the [Yes]. (Press the [▲] key or [▼] key)

NAV cancel
Yes
No

- 5 Press the [MENU] key. Then, the NAV is released.
- 6 To return the display to the original one, the display mode shall be switched over. (See: [1.4 Switch-over of Display mode])

Edit the destination

By entering the latitude and longitude, the destination can be preset.

The list preset in the past can be edit.

- 1 Press the [MENU] key.
- 2 Select [NAV] → [WPT edit]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the list No. to be edited from the [WPT edit] list. (Press the [▲] key or [▼] key)

WPT edit			
No.	Comment	Lat	Lon
1	WPT00001	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
2	WPT00002	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
3	WPT00003	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
4	WPT00004	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
5	WPT00005	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
6	WPT00006	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
7	WPT00007	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
8	WPT00008	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
9	WPT00009	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
10	WPT00010	XX° XXXX.XXXXN	XXX° XXXX.XXXX E


- 5 Press the [▶] key.

- 6 Select the character with the [▲] key or [▼] key. (Character: A ~ Z blank 0 ~ 9 +, - / Lat/Lon: 0~9 N S E W)

WPT edit			
No.	Comment	Lat	Lon
1	WPT00001	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
2	WPT00002	3X° XXXX.XXXXN	XXX° XXXX.XXXX E
3	WPT00003	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
4	WPT00004	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
5	WPT00005	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
6	WPT00006	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
7	WPT00007	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
8	WPT00008	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
9	WPT00009	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
10	WPT00010	XX° XXXX.XXXXN	XXX° XXXX.XXXX E

- 7 Move the position of characters to be reversed with the [◀] key or [▶] key.

WPT edit			
No.	Comment	Lat	Lon
1	WPT00001	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
2	WPT00002	35° XXXX.XXXXN	XXX° XXXX.XXXX E
3	WPT00003	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
4	WPT00004	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
5	WPT00005	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
6	WPT00006	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
7	WPT00007	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
8	WPT00008	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
9	WPT00009	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
10	WPT00010	XX° XXXX.XXXXN	XXX° XXXX.XXXX E

 **Caution:** If the values of latitude and longitude are not entered, they are registered as 0.

- 8 To end editing, press [GAIN (HF) Knob] or [GAIN (LF) Knob].
- 9 After finishing the edit work, press the [MENU] key.
- 10 Select the [registered] in the confirmation menu.

Edit end
Registered
Not registered

- 11 Press the [MENU] key. Then, the edit is finished.

Delete the waypoint

The destination list preset in the past can be deleted.

The deletion takes some time.

- 1 Press the [MENU] key.
- 2 Select [NAV] → [WPT delete]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the list number of the destination to be deleted from the [WPT delete]. (Press the [▲] key or [▼] key)

WPT delete			
No.	Comment	Lat	Lon
1	WPT00001	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
2	WPT00002	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
3	WPT00003	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
4	WPT00004	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
5	WPT00005	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
6	WPT00006	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
7	WPT00007	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
8	WPT00008	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
9	WPT00009	XX° XXXX.XXXXN	XXX° XXXX.XXXX E
10	WPT00010	XX° XXXX.XXXXN	XXX° XXXX.XXXX E

- 5 Press the [▶] key.
- 6 Select the [Yes] in the confirmation menu. (Press the [▲] key or [▼] key)

WPT delete
Yes
No

- 7 Press the [MENU] key. Then, the destination is deleted and the menu closes.

All WPTs deletes

All WPT lists can be deleted.

Recall the stored image and preset it as a destination

Recall the stored image in the past and it can be preset as a destination. (See [1.9 Use of [EVENT] key])


- 1 Press the [MENU] key.

- 2 Select [Image] → [Image recall]. (See [2.1 How to operate the menu].)
- 3 Press the [▶] key.
- 4 Select the image No. from the [Image recall] list. (Press the [▲] key or [▼] key)

Image recall	
No.	Comment
1	PIC00001
2	PIC00002
3	PIC00003
4	PIC00004
5	PIC00005
6	PIC00006
7	PIC00007
8	PIC00008
9	PIC00009
10	PIC00010

Caution: Chosen list NO. becomes yellow.

- 5 Press the [▶]key.
- 6 Move the cursor to the location preset as a destination with the[◀] key or [▶] key and select it.



Cursor (red line)

Caution: You can switch to other stored image with the [▲] or [▼] key.

- 7 When starting the NAV, press the [EVENT] key.

2.15 Store / Recall / Deletion of Image

Store the image

The present image of echo sounder can be stored.

To memorize, it takes some time.

To memorize the image, the [EVENT] key must be switched to the [Store image].

- 1 Press the [MENU] key.
- 2 Select [System] → [EVENT key set]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Store image]. (Press the [▲] key or [▼] key)

EVENT key set	
Store pos	
Store image	
Fishing hot spot	

- 5 Press the [MENU] key to close the menu.
- 6 When the echo sounder image to be stored appears, press the [EVENT] key.
- 7 When the stored image is fully filled, it shows that the [Store image] is fully filled. After deleting the unnecessary image, try it again.


Recall the stored image

The stored image in the past can be recalled.


During recalling, the image cannot be stored.

- 1 Press the [MENU] key.
- 2 Select [Image] → [Image recall]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the number of the image to be recalled from the [Image recall] list. (Press the [▲] key or [▼] key)

Image recall	
No.	Comment
1	PIC00001
2	PIC00002
3	PIC00003
4	PIC00004
5	PIC00005
6	PIC00006
7	PIC00007
8	PIC00008
9	PIC00009
10	PIC00010

 **Caution: Chosen list No. becomes yellow.**

5 Press the [▶] key.

 **Caution: When other stored image exists beside the recall image, switch to other images with the [▲] and [▼] key.**

6 Press the [MENU] key to return to the normal menu.

Delete the stored image

The stored image in the past can be deleted.

To delete, it takes some time.

- 1 Press the [MENU] key.
- 2 Select [Image] → [Image delete]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the number of the image to be deleted from the [Image delete] list. (Press the [▲] key or [▼] key)

Image delete	
No.	Comment
1	PIC00001
2	PIC00002
3	PIC00003
4	PIC00004
5	PIC00005
6	PIC00006
7	PIC00007
8	PIC00008
9	PIC00009
10	PIC00010

5 Press the [▶] key.

6 Select the [Yes] in the confirmation menu.

Image delete	
Yes	
No	

7 Press the [MENU] key.
Then, the preset image is deleted.

All stored image deletes

All stored image lists can be deleted.

Add the comment to the stored image

It is convenient to judge the stored image.

- 1 Press the [MENU] key.
- 2 Select [Image] → [Image comment]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the number of the image to which the comment is added from the [Image comment]. (Press the [▲] key or [▼] key)

Image comment	
No.	Comment
1	PIC00001
2	PIC00002
3	PIC00003
4	PIC00004
5	PIC00005
6	PIC00006
7	PIC00007
8	PIC00008
9	PIC00009
10	PIC00010

5 Press the [▶] key.

6 Select the character with the [▲] key or [▼] key. (Character: A ~ Z, blank, 0 ~ 9, +, -./)

Image comment	
No.	Comment
1	PIC00001
2	PIC00002
3	PIC00003

- 7 Select the comment position with the [◀] key or [▶] key.

Image comment	
No.	Comment
1	PIC00001
2	PIC00002
3	PIC00003

- 8 To stop editing, press [GAIN (HF) Knob] or [GAIN (LF) Knob].

- 9 After finishing the edit, press the [MENU] key.

- 10 Select the [register] in the confirmation menu.

Edit end
Registered
Not registered

- 11 Press the [MENU] key. Then, the edit is finished.

2.16 Explanation of Menu Item


The various items in the menu are explained.

Inner-hull

The reduction in sensitivity due to signal attenuation in inner-hull use can be corrected. (Setting: - 50 to 50: through-hull: 0)

- 1 Press the [MENU] key.
- 2 Select the [Adjust] → [Gain (TD)]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key. The image displays bottom only. It may show very strong fish targets.
- 4 Set a value to display the sea bottom continuously without interruption. For high frequency, turn [GAIN (HF) knob] and for low frequency, turn [GAIN (LF) knob].
- 5 Press the [MENU] key to close the menu.

⚠ Caution: Gain (TD) setting value widely varies upon installation conditions such as material of hull and installation method. Low frequency (50 kHz) may not be used due to large signal attenuation in some cases.



Change the TX power

The strength of transmission output (power) can be changed.

When the noise of interference with the neighboring echo sounder occurs, if the powers of transmission outputs at both sides are weakened, the interference noise can be suppressed.

In the [Auto] setting, the transmission output is automatically adjusted.

- 1 Press the [MENU] key.
- 2 Select the [Adjust] → [TX power]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [TX power]. (Press the [▲] key or [▼] key.)

TX power
20
30
40
50
60
70
80
90
100
Auto

- 5 Press the [MENU] key to close the menu.

⚠ Caution: In [Auto] setting, it controls transmission power automatically.

Change the Pulse width

Resolution and the detection distance change by changing the transmission pulse width. As for [Super short], the detection distance shortens though resolution goes up. As for [Long], the detection distance becomes long though resolution falls.

- 1 Press the [MENU] key.
- 2 Select the [Adjust] → [Pulse width]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Change the setting of [Pulse width]. (Press the [▲] key or [▼] key.)
- 5 Press the [MENU] key to close the menu.



Caution: When the fish symbol function is made effective, this function becomes invalid.

Change the Bandwidth

The bandwidth is automatically set according to the transmission pulse width. Please make it to [Narrow] when you decrease the noise. Please make it to [Super narrow] when you decrease more.

- 1 Press the [MENU] key.
- 2 Select the [Adjust] → [Bandwidth]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Change the setting of [Bandwidth]. (Press the [▲] key or [▼] key.)
- 5 Press the [MENU] key to close the menu.



Caution: When the fish symbol function is made effective, this function becomes invalid.

D.Range

D.Range is to expand and narrow down the signal range from blue to red in images.

When the value is small, the expression range of strong and weak signal change is narrow, weaker signal will become undistinguished. When the value is larger, the expression range is wider and the weaker signals become distinct.

(Setting: 12 to 30dB)

- 1 Press the [MENU] key.
- 2 Select the [Adjust] → [D.Range]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Change the setting of [D.Range]. (Press the [▲] key or [▼] key.)
- 5 Press the [MENU] key to close the menu.

Display Width

When the image is zoomed or the High frequency / Low frequency displayed, the display width can be changed.

- 1 Press the [MENU] key.
- 2 Select the [D.range] → [Disp. width]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the width of image. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Display the A scope / Stop the display of A scope

The echo strength of latest echo can be displayed at the right side of echo sounder display.

The strength of echo sounder image is expressed by the horizontal width. This expression is called [A scope].

The width for strong echo is wide and the width for weak echo is narrow. This makes it easier for you to see the echo.

- 1 Press the [MENU] key.
- 2 Select the [Display1] → [A scope]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 To display the A scope, select the [ON]. To stop the display of A scope, select the [OFF]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Change the display color of echo sounder image

The [Monochrome], [8 color], [16 color] and [64 color] can be selected.

- 1 Press the [MENU] key.
- 2 Select the [Display1] → [Color tone]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Color tone]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Change the depth value

The display size of depth value can be changed.

- 1 Press the [MENU] key.
- 2 Select the [Display1] → [Depth value]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the size of display. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Display the depth unit / Stop the display of depth unit

The depth unit can be displayed.

- 1 Press the [MENU] key.
- 2 Select the [Display1] → [Unit display]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 To display the depth unit, select the [ON]. To stop the display of depth unit, select the [OFF]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Display the water temp graph / Stop the display of water temp graph

The latest water temp value and the graph of past water temp data can be displayed.

- 1 Press the [MENU] key.

- 2 Select the [Display1] → [Water temp graph]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 To display the water temp graph, select the [ON]. To stop the display of water temp graph, select the [OFF]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Setting of the background color of NAV display

The color of background of navigation display (NAV1, NAV2) can be changed.

- 1 Press the [MENU] key.
- 2 Select the [NAV] → [Background color]. (See [2.1 How to operate the menu].)
- 3 Press the [▶] key.
- 4 Select the [Background color]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Setting of the echo sounder display at NAV display

The sounder display can be selected at NAV (NAV 1, NAV 2) to be displayed.

- 1 Press the [MENU] key.
- 2 Select the [NAV] → [NAV1 (2)]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the echo sounder display at [NAV 1] or [NAV 2] to be displayed. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Image Swap

The images of echo sounder at the right and left sides can be swapped.

- 1 Press the [MENU] key.
- 2 Select the [Image] → [Image swap]. (See [2.1 How to operate the menu])

- 3 Press the [▶] key.
- 4 Select the swap state[A|B],[B|A]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Display the Operation guide/Stop the display of Operation guide

When displaying the menu, it sets whether or not the operation guide is displayed at the lower part on the display.

When setting to “No display of operation guide”, the echo sounder image can be easily seen at the menu operation.

- 1 Press the [MENU] key.
- 2 Select the [System] → [Operation guide]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 To display the Operation guide, select the [ON].
To stop the display of Operation guide, select the [OFF]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Display the detection area / Stop the display of detection area

The range of the search that can be detected in the angle of beam spread of the transducer used can be displayed.

- 1 Press the [MENU] key.
- 2 Select the [Display2] → [Detection area]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 To display the Detection area, select the [ON].
To stop the display of Detection area, select the [OFF]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.



Caution: The beam angle of transducer is different depending on the transducer. (See [3.3 Setting of Correct Item, Directirity angle (Low/High)].)

Setting of Scale display

The set of the scale display

- 1 Press the [MENU] key.
- 2 Select the [Display2] → [Scale display]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Scale display]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Change the scale value

The display size of the scale value can be changed.

- 1 Press the [MENU] key.
- 2 Select the [Display2] → [Scale]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Scale]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Change the image direction

Selects the direction of display image.

- 1 Press the [MENU] key.
- 2 Select the [Display2] → [Image direction]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Image direction]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Setting of Depth measurement

Selects the method for depth measurement, which is shown on the display.

- 1 Press the [MENU] key.
- 2 Select the [Display2] → [Bottom detection]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Bottom detection]. (Press the [▲] key or [▼] key)

- 5 Press the [MENU] key to close the menu.

Change the display color

The display color can be changed.

- 1 Press the [MENU] key.
- 2 Select the [Display2] → [Color table 1] or [Color table 2]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Color table]. (Press the [▲] key or [▼] key)
- 5 Press the [▶] key.
- 6 Select the color. (Press the [▲] key or [▼] key)
- 7 Press the [MENU] key to close the menu.

Setting of Key lock

Disables the functions of controls and keys to avoid deviation of these settings by unintentionally touching them during operation.

- 1 Press the [MENU] key.
- 2 Select the [System] → [Key lock]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Key lock]. (Press the [▲] key or [▼] key)
- 5 Press the [▶] key.
- 6 Select the [ON] or [OFF]. (Press the [▲] key or [▼] key)
- 7 Press the [MENU] key to close the menu.

Sub Depth Value

Depth value can be displayed with the selected depth unit independently in addition to the Main depth value.

- 1 Press the [MENU] key.
- 2 Select the [System] → [Sub Depth Value]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the Sub Depth unit from [m], [fm], [l.fm] or [ft].

To stop the display of Sub Depth Value, select [OFF]. (Press the [▲] key or [▼] key)

- 5 Press the [MENU] key to close the menu.

Change the User setting

A set value of the menu entry can be memorized by four patterns. It is convenient to switch the pattern according to the purpose of the fishery.



Caution: The unit set to [1] at the factory.

- 1 Press the [MENU] key.
- 2 Select the [System] → [User set]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [2]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.
- 6 When a set value of the menu entry is changed, it is automatically memorized in [2].
- 7 [3] and [4] also memorize a set value of the menu entry by a similar operation, and it is possible to switch.

Change the scale type

The interval of indications of scale can be changed.

- 1 Press the [MENU] key.
- 2 Select the [Display2] → [Scale type]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Scale type]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Change the bottom color

The dark red color of sea bottom can be changed.

- 1 Press the [MENU] key.
- 2 Select the [Display2] → [Color table 2] → [Bottom color]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Bottom color]. (Press the [▲] key or [▼] key)
Black ← 0, , , 176, , , 255 → Red
- 5 Press the [MENU] key to close the menu.

Change the image partition

The image partition of echo sounder can be change to "Horizontal split" or "Vertical split".

- 1 Press the [MENU] key.
- 2 Select the [Image] → [Image partition]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [Image partition]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Selecting a display area of fish symbol indication

The fish symbol can be displayed either on side A or on side B, or on both sides, by the following operation.

- 1 Press the [MENU] key.
- 2 Select the [Image] → [Fish image]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [A|B], [A|], [|B]. (Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Display Bottom Hardness value

The Bottom Hardness value is displayed in the % value at the bottom of the screen.

This % value is displayed by [PKODS4] sentence output.

- 1 Press the [MENU] key.
- 2 Select the [Display2] → [Bottom Hardness]. (See [2.1 How to operate the menu])
- 3 Press the [▶] key.
- 4 Select the [ON] to display the Bottom Hardness.
Select the [OFF] to stop the display of Bottom Hardness.
(Press the [▲] key or [▼] key)
- 5 Press the [MENU] key to close the menu.

Caution: The % value varies depending on the topography of the sea bottom, transducer type and frequency. Please adjust with [BTMH adjust]. (See [3.6 Setting of Adjust2 Item, BTMH adjust])

<Example display>



↑
Bottom Hardness

- This page intentionally left blank.-

Chapter 3 How to use the menu2

3.1 Display of Menu

After powering on, besides the menu displayed first with the [MENU] key, there are the other menus as follows, of which setting does not need to be frequently changed.

[In out], [Correct], [Setting], [Maintain]

Display the menu

- 1 Press the [MENU] key.
- 2 Select the [Next].

Adjust	In out
D.range	Correct
Display1	Setting
Display2	Maintain
Alarm1	Adjust2
Alarm2	
NAV	
Image	
System	
Freq	
Next	

- 3 Press [▶] key to display the system menu.

Prev	Adjust
In out	D.range
Correct	Display1
Setting	Display2
Maintain	Alarm1
Adjust2	Alarm2
	NAV
	Image
	System
	Freq

Return to the normal menu

- 1 Select the [Prev].
- 2 Press the [▶] key to display the normal menu.

3.2 Setting of External Input / Output

Set the setting related to the input/output.

Prev	Buzzer setting	OFF
In out	Temp source	ST/TC
Correct	Speed source	InsideSensor
Setting	Baud rate	4800
Maintain	NMEA monitor	OFF
Adjust2	NMEA output data	
	NMEA output data	
	Ext synchronized	OFF
	Unreceived sync	Stop
	Return	

Buzzer Setting

Set the buzzer sound to ON/OFF.

Temp Source

Switch the ST/TC or NMEA.

For setting of [ST/TC] (sensor), use an internal water thermometer connected to the water temperature sensor with J6 connector.

For setting of [NMEA], use the input value from outside connected with NMEA of J3 connector.

Speed Source

Switch the Sensor or NMEA.

Use the built-in speed meter for sensor*.

Use the external input value for NMEA.

Baud Rate

Change the transmission speed of external input/output.

Match the transmission speed with that of external equipment connected. (Setting: 4800, 9600, 19200, 38400)

NMEA Monitor

The external input data can be displayed.

To return to the original menu, press the [MENU] key.

 **Caution:** When [GAIN (HF) Knob] is pressed, the displayed data will stop.

NMEA Output Data

The output of NMEA sentence can be set to ON/OFF.

- 1 Select [In out] → [NMEA output data]. (See [2.1 How to operate the menu].)
- 2 Press the [▶] key.
- 3 Select the sentence name.
- 4 Press the [▶] key.

Prev	Prev	
In out	DBT	ON
Correct	DPT	ON
Setting	GGA	OFF
Maintain	MTW	OFF
Adjust2	TLL	ON
	VHW	OFF
	VTG	OFF
	ZDA	OFF
	Return	

- 5 Select the ON/OFF.

DBT
OFF
ON


- 6 Press the [◀] key to turn to the display to select the sentence name.
- 7 Further pressing of [◀] key turns to the display to select the NMEA output.
- 8 Press the [MENU] key to close the menu.


External synchronous input

It is likely to interfere mutually when the transmit frequency of an external echo sounder and this unit is the same or it approaches.

Interference can be decreased by transmitting this unit synchronizing with the trigger of an external echo sounder.

- 1 Select [In out] → [Ext synchronized]. (See [2.1 How to operate the menu].)
- 2 Press the [▶] key.
- 3 Change the setting of [Ext synchronized]. (Press the [▲] key or [▼] key.)
- 4 Press the [MENU] key to close the menu.

 **Caution:** The image speed stops when making it to [] or [] when the synchronized signal from an external echo sounder uninputs it to this unit.

 **Caution:** The unit always outputs the synchronized signal.

Unreceived synchronization

The image scroll stops if synchronization signal from an external echo sounder is not received. The operation for the case is as follows.

- 1 Select [In out] → [Unreceived sync]. (See [2.1 How to operate the menu].)
- 2 Press the [▶] key.
- 3 Change the setting of [Unreceived sync]. (Press the [▲] key or [▼] key.)

If [Stop] is selected, the image scroll stops when there is no synchronous signal from an external sounder.

If [Auto] is selected, the image scroll starts by TX/RX this equipment when there is no synchronous signal from an external sounder.

- 4 Press the [MENU] key to close the menu.

3.3 Setting of Correction Item

Prev	Draft set	0.0m
In out	Sonic speed	Seawater
Correct	Water temp	0.0°C
Setting	Boat speed	0%
Maintain	Beam width H	17°
Adjust2	Beam width L	50°
	Size adjust	6
	Detect adjust f	4
	Bubble	OFF
	Bubble time set	1 minutes
	Return	

Draft Set

The tolerance of depth can be corrected.

Set the depth from the sea level to the set depth of your transceiver/receiver. Normally set draft value of your boat. (Setting: expect ft: - 10.0 to 10.0, ft: -30.0 to 30.0)

Sonic Speed

Set the [Seawater] or [Freshwater].
Change to meet the usage.

Water Temp

The error of water temp value can be corrected.
(Setting: - 10.0 to 10.0 °C, - 10.0 to 10.0 °F)

Boat Speed

The tolerance of boat speed value can be corrected.

When the [Speed source] is set to the [InsideSensor], it is corrected by %. (Setting: - 50 to 50 %)

When the [Speed source] is set to the [NMEA], it is corrected by numeral. (Setting: - 10.0 to 10.0)

Directivity angle (Low/High)

Directivity angle of transducer which you use should be input for high and low frequency respectively.

Bubble

Bubble-prevention process can be activated by setting [Weak] or [Strong].

Bubble time set

While auto-range or auto-shift is in use, and if the missing image is caused by bubble, range and shift continues changes until sea bottom is detected by auto mode.

Setting the bubble time duration holds the range or shift at the level when bubble started.

If bubble disappears and sea bottom is detected, range or shift returns to auto mode.

This makes the time shorter until the image comes back to normal. After the specified time, the mode returns to the previous auto-range or auto-shift. (Setting: OFF, 1min to 10min)

3.4 Setting of Basic Set Item

Prev	Language	English
In out	Range&Speed unit	NM,kn
Correct	Depth unit	m
Setting	Temperature unit	°C
Maintain	Localtime offset	0.0
Adjust2	GPS select	Others
	GPS initialize	No
	Bottom srart	1.5
	Past image	ON
	Return	

Language

Switch to the language to be displayed.



Caution: [Language] is displayed in red characters.

Range & Speed Unit

It switches the display unit to [NM, kn] or [km, km/h].

Depth Unit

It switches the unit of depth to m, fm, l.fm and ft.

Temperature Unit

It switches the unit of temperature to °C, °F.

Local time Offset

The local time offset can be set by 0.5 hours (30 minutes) unit. (Setting: - 11.0 to 14.0 h) (UTC: 0.0)

GPS select

It selects whether the GPS sensor is the KODEN made one or not.

Caution: Only when connecting the Koden GPS sensor to the equipment directly, select [KODEN GPS]. When connecting the GPS sensor (even Koden one) via Plotter etc to the equipment, select [Other].

GPS initialize

It is valid only when KODEN GPS is connected.

The GPS sensor is initialized.

Caution: When connecting the GPS sensor other than KODEN GPS, do not use this item.

Bottom start

Set up the starting depth of the seabed detection. Once set, the fish echo or the seabed shallower than set up depth will not be detected.

Past image

When the [Past image] is set to ON, the gain control is effective for all screens including the past image.

When the [Past image] is set to OFF, the gain control is effective for current image only.

3.5 Maintenance Menu

Prev	Simulation	OFF
In out	Slideshow	OFF
Correct	Initialize	No
Setting	System check	
Maintain	Inner-hull	No
Adjust2	TD select (H)	TDXXXX
	TD select (L)	TDXXXX
	Ferrite	OFF
	XID	
	Return	

Simulation

When the [Simulation] is set to ON, the pseudo image of echo sounder is displayed.

Slide show

The slide show of the images stored in [Image]→[Image recall] is available. The time intervals for image changeover can be selected from 15 seconds and 30 seconds.

Caution: To perform slide show, registration in the list of image memory is required. When it is not registered, slide show cannot be selected.

Initialize

It returns all the settings in the menu to the factory settings. However, the memorized data of display remains unchanged.

Caution: It returns to the factory settings and the power is automatically shut down.

System Check

It is used for diagnostic test.

(See [4.5 Diagnostic Test])

Inner-hull

When the installation of a transducer is [Inner-hull], select the [Yes].

Caution: When a setting is altered, the value of Gain (TD) will be initialized.

TD select (H) / (L)

Select the type of transducer to be actually used.
See [Transducer and Frequency] for details.

Ferrite

Can be set when [TD select (L)] is set to [Other 3kw].

“Checking” is displayed while checking the connection of the transducer.

Caution: If you want to set it to [ON], please contact our sales company or our dealer.

XID

XID data acquired from the XID-adaptive TD is displayed on the XID screen. XID data have the TD name, serial number, etc.

Press the [▶] key to switch pages.

Press the [Menu] key for 3 seconds or longer to exit the XID screen.

3.6 Setting of Adjust2 Item

Prev	STC strength H	0.0
In out	STC depth H	50
Correct	STC strength L	0.0
Setting	STC depth L	50
Maintain	Color adjust	
Adjust2	Image speed adj	0
	Bottom limit	1.0
	Sounding	200m
	BTMH adjust	1.00
	Return	

The visibility of the fish school echo can be adjusted by STC setting.

Adjustment can be done for high-frequency and low-frequency independently.

STC strength adjust Low / High

Set smaller values for higher sensitivity.

STC depth adjust Low / High

Depth limitation of STC adjustment.

Unit: Meter

STC can be operated from 0 to the setting depth.

Color adjust


Rainbow pattern of the echo image can be changed.

Set the value of each color in the range from 0 to 99%. Confirm color distribution by the rainbow pattern of the left side of the screen.

Prev	Prev	
In out	Red	95
Correct	Orange	90
Setting	Yellow	60
Maintain	Green	30
Adjust2	Sea green	20
	Light blue	15
	Marine blue	5
	Return	

EXAMPLE:

When the yellow value is change from 60 to 80 in the setting, the Rainbow pattern becomes as shown below.



Before the change

After the change

Image speed adjust

The image speed can be adjusted.

The image speed becomes faster in a minus direction, and slower in a plus direction.

 **Caution: Image speed cannot set faster than the maximum speed value.**

Bottom limit

The detection of sea bottom can be changed.

Sea bottom can be detected up to the range of display multiplied by the setting value.

EXAMPLE:

Displayed 20 m, setting value: 2.0, a bottom can be detected up to approximately 40m.

 **Caution: If the setting value is increased, the image speed becomes slower.**

Sounding

Sounding is performed up to the maximum depth set during auto range is in operation.

The maximum range is 2000 m. At the initial setup, the range is up to 1000 m. (Setting: m: 10 to 2000, l.f.m: 10 to 1100, f.m: 10 to 1100, ft: 10 to 6000)

BTMH adjust

The % value of bottom hardness can be adjusted.


The smaller the setting value, the smaller the % value.

3.7 Frequency Select

Adjust	Freq select (H)	200.0
D.range	Freq select (L)	40.0
Display1	Power freq adj H	118.5
Display2	Power freq adj L	118.5
Alarm1	Freq display	ON
Alarm2	Return	
NAV		
Image		
System		
Freq		
Next		

Frequency select (H) / (L)


Select the frequency (low frequency and high frequency) of the connected transducer.

 **Caution: Do not select a frequency that is different from the frequency of the connected transducer.**

Power frequency adjustment H / L

It is necessary to adjust power frequency when noise appears on the image. The value for adjustment depends on the frequency of the transducer.

If internal noise occurs on the screen, adjust [Power freq adj H] for high frequency screens and [Power freq adj L] for low frequency screens.

 **Caution: [Power freq adj H] and [Power freq adj L] are adjustments for the internal noise of the device. Therefore, it cannot deal with external noise.**

Display the frequency / Stop the display of frequency

The frequency of the transducer currently in select can be displayed.

Chapter 4 Maintenance and Inspection

4.1 Inspection

The daily maintenance and inspection extends the life of equipment. To always keep the equipment in the best condition, implement periodically the inspection shown in the table below.

Item	Content of Inspection
Connector at the rear of Display unit	Check the looseness.
Wiring of cables	Check the wiring of cables connecting the equipment and the damage of cable.
Grounding of display unit	Scrape the rust off the ground terminal and make its contact well.

4.2 Cleaning



Display unit

Contamination on the screen may cause faint images. For cleaning the screen, wipe the screen with soft and clean cloth dipped with diluted neutral detergent. Pay full attention as the screen is easily getting scratched. No thinner shall be used.



Caution

The display unit has a special coating. Do not use a solvent such as paint thinner, acetone, alcohol, and benzene, etc.
Strong rubbing may cause bruising and scratching.



For cleaning the housing, do not use a solvent such as thinner or alcohol. Painting on the surface and characters at the operating portion may melt. After wiping with soft and clean cloth dipped with diluted neutral detergent, wipe away with dry soft and clean cloth.

Transducer

In case of through-hull equipped transducer, check the surface of opening of transducer (portion from which the ultra-sonic is emitted). If shells and oil are stuck, scrub the surface with a wooden or bamboo knife with caution not to damage the surface and remove stuck materials. If you scrub strongly, the surface will be damaged, resulting in deteriorated performance of transducer.

4.3 Fuse Replacement



Warning

Use the specified fuse. If you use a fuse other than specified one, it may lead to a serious accident.

If the input voltage is too high, the over-current flows or a trouble occurs inside, the fuse will blow out. The fuse is housed in the power cable.


4.4 If you suspect a trouble

Symptom	Possible cause of trouble	Countermeasure
Even if the power is powered on, nothing is displayed.	<ul style="list-style-type: none"> • Blown fuse. • The power voltage is out of specification (10.8 to 31.2 VDC). • Poor connection between power cable and battery. 	<ul style="list-style-type: none"> • Exchange a fuse. (See [4.3 Fuse Replacement]) • Use a proper power as per specification. • Confirm a connection between the power cable and the battery.
The unit starts up. But, nothing is displayed on the display.	<ul style="list-style-type: none"> • Connection between transducer and display unit. • Defect of LCD display block. 	<ul style="list-style-type: none"> • Confirm a connection between Transducer and Display unit. • Consult a repair shop or the distributor in your market.
Too much interference and noise.	<ul style="list-style-type: none"> • Installed position of transducer. • Interference from the echo sounder on other boat. 	<ul style="list-style-type: none"> • Confirm the position of transducer. (See [5.5 Installation of Transducer]) • Apply the interference rejection. (See [2.3 Rejection of Interference])
The display of water temperature / boat speed is abnormal or not displayed.	<ul style="list-style-type: none"> • Connection of sensor connector. • Input source of water temperature sensor / speed sensor. 	<ul style="list-style-type: none"> • Confirm the connection of the sensor connector. • Confirm the input source.
The display of present location/course is abnormal or not displayed.	<ul style="list-style-type: none"> • Connection between this unit and navigation equipment. 	<ul style="list-style-type: none"> • Confirm a connection between Display unit and the navigation equipment.

4.5 Diagnostic Test

Perform the operation diagnosis.

To check the operation diagnosis of panel key, the state of sensor inside and the version of software.



Diagnose

① displays the diagnostic result.

The result of ROM and RAM check displays OK when normal and NG when abnormal.

Caution: To test the NMEA, TEMP and SPEED, the special checker is necessary.

② implements the key input test. When pressing the key, the color of a part corresponding to the pressed key changes.

When pressing the [GAIN (HF)], the LCD test is performed.

Confirm the version

③ displays the information on the version of software.

When inquiring, inform us of Ver XX.XX.

Return to the menu

Press the [MENU] key for more than 3 seconds.

- This page intentionally left blank.-

Chapter 5 Installation

5.1 Items of Caution on Installation

To realize the full performance of echo sounder, the installation of this unit must be performed by an engineer who is officially authorized by our company. The installation work includes the following content.

- (1) Unpacking the components
- (2) Inspection of configuration unit, spare, accessories and material for installation
- (3) Check of power voltage and capacity of current
- (4) Decision of installing location
- (5) Installation of Display unit and transducer
- (6) Installation of accessories
- (7) Plan and execution of cable laying and connection
- (8) Adjustment after completion of installation

Unpacking the components

Unpack the components and confirm that all of the items match with the contents on the equipment configuration list. If not matched, Contact the dealer you purchased or our sales company.

Inspection of components and accessories

Inspect the appearance of each component and accessories and check that no dents or damage exist.

If any dents or damage exist and they are believed to be caused by accident during transportation, contact the transportation and insurance company and consult our sales company or our dealer nearest to you.

Decision of Installing Location

To realize the full performance of equipment, install the equipment, considering the points mentioned below.

- (1) Install the equipment at the location in the bridge so that its display can be easily seen.
- (2) Select a safe location where the equipment is not exposed to humidity, water splash, rain and direct sunshine.
- (3) Keep enough space for maintenance. Especially, secure enough space at the rear panel where many cables are concentrated.
- (4) Keep the equipment as far away from the wireless transmitter/receiver as possible.



Caution

The equipment is not waterproof. Avoid excessively damp place. Do not install the equipment in the place suffering from excessive water-drops. Otherwise, the corrosion may occur inside.

Laying and Connection of Cable

- (1) Keep the transducer and power cable as far away from the cables of other electronic equipment as possible.
- (2) The cabinet of Display unit shall be securely grounded to the hull, using the ground terminal on the rear panel.



Caution: The ground side of power input of this equipment is connected to the ground terminal. In case of + (positive) ground, it cannot be used. The power may short-circuit.

- (3) If you connect the power cable directly to the battery, the interference from other electronic equipment is not subject to occurrence. (See Fig. 5.1.1)




Fig. 5.1.1 Connection of Power Line

Confirmation after Installation

Be sure to confirm the following items before starting up this equipment. The confirmation is mandatory to operate the equipment normally.

- (1) Is the power voltage in the boat within the appropriate voltage range? Is the current capacity enough?
Voltage Range: 10.8 to 31.2 VDC when measured at the power connector input.
- (2) Is the electric current capacity sufficient? (Power consumption: 50 W)
- (3) Is the wiring of transducer cable correct? Is the wiring shorted?

5.2 Installation of Display unit

Display unit can be installed either on desk-top or flush-mounted.

Install in the following procedure.

Desk-top Installation

- (1) Remove two knob bolts fixing the display unit to the bracket.
- (2) Remove the display unit from the bracket and place it on the stable flat place.
- (3) Place the bracket on the position where the display unit will be installed and fix the bracket with five 5 mm screws.
- (4) Place the display unit on the installation bracket and fix the display unit with two knob bolts removed in step 1.




Fig. 5.2.1 Desk-top installation



Caution: When installing on the desktop, the maintenance space shown in the illustration below is required for cable lay-out, plugging-in/out of connector, fuse replacement and bolt tightening.




Fig. 5.2.2 Maintenance space

Unit: mm (inch)

Flush-mount Installation

- (1) Make a square hole at the location to be installed. (See Fig. 5.2.4)
- (2) Turn counter-clockwise the knob bolt fixing the display unit to the mounting bracket to loosen it, push the unit to the left side and pull the unit upward. The mounting bracket and knob bolt are not used.
- (3) Remove four plastic screw covers, which are fitted on each corner of the display front face.
- (4) Confirm that the unit matches with the square holes. If not matched, correct the square hole.
- (5) Connect the connectors for power and transducer to the unit respectively.
- (6) Install the display unit in the installing location (square hole) and fix it with four 4mm tapping screws (or M4 pan-head). (Prepare 4mm screws suitable for thickness of installing location.)
- (7) Refit the coverings removed in step (3).




Fig. 5.2.3 Flush-mount Installation




Fig. 5.2.4 Work of flush-mount installation hole

5.3 Wiring

Connection of Cable to Display unit

Connect the power cable and transducer to the connectors of Display unit.





Fig. 5.3.1 Cable connections

*Note 1: TD-501C, TD-501T-3B, TDM-031D, TDM-071, TDM-091D and "Other 1kW" TD

Pin Assignment of Rear Connector

Pin assignment viewed from the rear of Display unit.



Caution: Do not connect each wire to ship's earth.

Fig. 5.3.2 Pins assignment of rear connector

Connection of Power Cable

Connect the power cable to the [POWER] connector and the transducer to the [J6] at the rear of Display unit connector.

Connection of DC power cable (CW-259-2M)




Fig. 5.3.3 Connection of DC power cable



Caution: Wind the insulation tape around the un-used lead wire for core-wires not to contact each other.



Caution: Confirm the main switch-board off before connecting power cable.

Grounding

- Use heavy gauge cable for grounding wire.
- Connect the grounding wire to the grounding material in a short distance.
- When connecting the external equipment of which positive polarity is connected to the ground line, do not connect the ground of signal line to the cabinet ground.

Connection with external echo sounder

It is likely to interfere mutually when the transmit frequency of an external echo sounder and this echo sounder is the same or close. Interference can be decreased by synchronizing the echo sounder transmission with the trigger of the external echo sounder. Refer to the following for the connection.

Connector	Pin	Remark
J1	①	External trigger input (+)
	②	External trigger input / output (-)
	③	External trigger output (+)
	④	Un-connected
	⑤	Un-connected




Fig. 5.3.4 External trigger

Connection with external navigation equipment

The NMEA data can be output from this echo sounder to an external navigation equipment, and the NMEA data can be input from an external navigation equipment to this echo sounder. Refer to the following for the connection.


connector	Pin	Remark
J3	①	Outside Power (-)
	②	NMEA TX+
	③	NMEA TX-
	④	NMEA RX+
	⑤	NMEA RX-
	⑥	Outside Power (+)

Connection with Ship Speed Sensor or Water Temperature Sensor (Option)

When installing the optional speed sensor or water temperature sensor, connect to the [J6] connector together with the transducer via the transducer cable (Type: CW-840-0.3M). For wiring, see the figure below.

! After soldering, implement the waterproof and insulation treatment on the connected part with the self-melting tape.

Structure of Transducer Cable



! **Caution:** Wind the insulation tape around the un-used lead wire for core-wires not to contact each other.

Fig. 5.3.5 CW-840-0.3M ship speed sensor, water temperature sensor connection diagram

Connection Table of Speed Sensor and Water Temperature Sensor*

Transducer Cable		Water Temperature Sensor* / Speed Sensor			
No. of lead wire	Color of lead wire	T-81	ST-80 ST-80-1	ST-90 ST-90-1	ST-100 ST-100-1
1	Blue	-	Green	Green	Green
2	Violet	-	Red	Red	Red
6	Green	Gray	White	White	White
7	Red	Gray	Brown	Brown	Brown
8	Black	-	Shield	Shield	Shield

*Connect the water temperature sensor (TC02CS, TC03-10) referring to the connection instructions attached to the device.

! **Caution:** No.8, SPD.GND (Black), only use for speed sensor.
Do not connect with other grounding wire.

Connection of External Monitor (J5) (Prepared by a customer)

When installing an external monitor (VGA monitor, analog RGB input), connect it via CW-576-0.5M.
For its wiring, refer to the illustration below.

After soldering, perform the waterproof and insulation treatment on the junction with a self-fusion tape.


Structure of CW-576-0.5M

Fig. 5.3.6 Connection of External Monitor

Input Data

Information	Priority Order of Sentence	Information	Priority Order of Sentence
Latitude, Longitude	GGA > RMC > GLL	Wind Direction	MWV
Course	VTG > RMC	Wind Speed	MWV
Heading	THS > HDT	Date	ZDA > RMC
Ground Speed	VTG > RMC	Time	ZDA > GGA
Water Speed	VHW	Water Temperature	MTW

Sentence	Information	Sentence	Information
DBT	Depth from the transducer	MWV	Wind Direction, Wind Speed
DPT	Depth from the transducer, Draft	RMC	Latitude/Longitude, Course, Ground Speed, Date
GGA	Latitude/Longitude, Time	TLL	Target Position
GLL	Latitude/Longitude	VHW	Water Speed
HDT	Heading	VTG	Course, Ground Speed
MTW	Water Temperature	ZDA	Date, Time
Olex	PKODS,2 Used at 38400 bps	Nobeltec	PKODS,3
PKODS 4	Depth. Bottom Hardness		

PKODS,4	<p>Depth and Bottom Hardness (KODEN's private sentence)</p> <p>\$ PK ODS,4,D,xxx.x,c--c,H,xxx,*hh<CR><LF></p> <p> \$ PK ODS,4 D xxx.x c--c H xxx *hh <CR> <LF> Talker device Sentence Name Depth Bottom Hardness (%) Checksum Start of sentence Depth unit(M,FT,FA,IFA,HR) </p>
---------	---

An example of each equipping method is shown below.

Cautions on installation of transducer

1. Not affected by air bubbles

If the transducer is installed incorrectly, air bubbles may adhere to the radiation surface of the transducer when the ship sails, making it impossible to receive ultrasonic wave. To exclude the influence of air bubbles, it is effective to increase the protruding of the transducer from the bottom of the ship. It is also effective to move the installed position of transducer away from the keel line.

2. Not receive noise from screws

Noise may be displayed on the screen when the screw speed is increased. In this case, replace the screw or install the transducer away from the screw.

3. Not receive noise from the engine

If the echo sounder receives noise from the engine, move the installed position of transducer away from the engine.



Cautions for installation XID-adaptive TD^{*1}

TDM-031D/052A/062A/071/083/091D are XID-adaptive TD^{*1}. When using an XID-adaptive TD^{*1}, the ship's speed sensor cannot be used.

^{*1} XID-adaptive TD: Transducer with a function to output internal information (internal temperature, element characteristics, etc.).

Pay attention to the following when installing XID-adaptive TD^{*1}.

- **Be sure to install the transducer in an external tank. Be sure to immerse the wave transmitting surface (bottom) and sides of the transducer in seawater to cool the unit.**
- **Do not cover the XID-adaptive TD^{*1} with FRP. Do not install the transducer inside the inner-hull tank. Doing so may cause the transducer to overheat resulting in failure.**
- **Do not install in the engine compartment or other hot place. The temperature around the transducer will become high, causing the transducer to overheat resulting in failure.**
- **Always operate the transducer in water. Operating in air will allow the transducer to overheat resulting in failure.**

This unit monitors the internal temperature of the transducer to protect it from failure due to overheating. When TDM-052A/062A/083/091D is connected, this unit controls the transmission output etc. to prevent the transducer from overheating by monitoring the internal temperature of the data received from the transducer.



Caution: If the internal temperature of the transducer becomes high, the temperature control may reduce the sensitivity of the image. For safe use, consult your dealer if temperature control is activated frequently.

In case of Inner-hull

The standard installation of the transducer is shown in figure 5.5.1




Figure 5.5.1 Installation of Transducer

Using the optional inner-hull kit, install the transducer to the inner side of ship's bottom.

Caution on installation

- (1) Select the location where no bubble is generated during navigation.
- (2) Select the relatively thin location of ship's bottom. (About 6mm)
- (3) Be sure to remove oil on the contact surface. File the contact surface with sand paper (#400) so that the adhesive strength will increase.
- (4) The adhered surface will dry in about two hours.
- (5) Leave the unit for a whole day and fill in the coolant. More than 80 % of the transducer should be submerged in the coolant




Figure 5.5.2 Inner-Hull installation



Caution: It is strongly recommended to confirm the location of the installation of Inner-hull with the ship manufacturer. The Inner-hull device is more simplified method. The gain falls dramatically in comparison with the Through-hull performance. Low frequency (50 kHz) may not be used due to large signal attenuation in some cases. Depth range performance using 200 kHz Transducer in case of Inner-hull can be less about 50% than that of Through-hull.



Caution: Fishing boats may have structure with FRP contained air bubbles and foamed materials that would prevent ultrasound from penetration. Therefore, the location convenient for installation may not be locations where attenuation of ultrasound is low enough.

In case of ship side installation

Cut a PF1 1/2 pipe parallel screw (P = 2.3091) in the 1 1/2 inch pipe, screw in the transducer, and fix it with the lock bolt.

Attach the pipe receiving bracket and tightening bracket to the ship's side so that this bolt can be moved up and down and removed.

Raise the pipe above sea level to avoid water pressure during the voyage. When using it, lower it as deeply as possible so that it is not affected by air bubbles.

During use, fix the front and back of transducer with a rope so as not to turn by water pressure.




Fig.5.5.3 TD ship side installation diagram

In case of the ship's bottom installation

Various types of rectifying tanks (Turbulence Minimizing Enclosure) are prepared according to the material of the ship's hull or transducer frequency used. Mount the rectifying tank to the ship's bottom before mounting the transducer to in the rectifying tank. The more the tank protrudes, the less the water turbulence. The following drawing illustrates an example of the through-hull installation.




Fig 5.5.4 An example of the through-hull transducer installation

Installation of TDM-052A / 062A / 083

1) In the case of steel boat

With reference to the figures below, install the transducer at a shipyard.




Fig. 5.5.5 Transducer TDM-052A/062A/083 installation diagram 1

No.	Name	Material	Qty	Remarks
[1]	Transducer unit (with bottom plate)		1	
[2]	Cable gland (CG-1)	SS400	1	
[3]	Tank	SS400	1	By shipyard
[4]	Mounting bolts	SUS304	4	




Fig. 5.5.6 Transducer TDM-052A/062A/083 installation diagram 2

Transducer installation



- Caution:** 1. Plumbing pipe and welded plate or rod in dotted lines shall be provided by the shipyard after specifying the details.
 2. Preferably larger amount of protruding could produce better performance because it is hard to be influenced by bubble.

2) In the case of steel boat (For Anti-resonance)

With reference to the figures below, install the transducer at a shipyard.




Fig. 5.5.7 Transducer TDM-052A/062A/083 installation diagram 3

No.	Name	Material	Qty	Remarks
[1]	Transducer unit (with bottom plate)		1	
[2]	Cable gland (CG-1)	SS400	1	
[3]	Tank	SS400	1	By shipyard
[4]	Mounting bolts	SUS304	4	




Fig. 5.5.8 Transducer TDM-052A/062A/083 installation diagram 4

Transducer installation (For Anti-resonance)

- Caution:** 1. Plumbing pipe and welded plate or rod in dotted lines shall be provided by the shipyard after specifying the details.
 2. Preferably larger amount of protruding could produce better performance because it is hard to be influenced by bubble.

3) In the case of wooden and FRP boat

With reference to the figures below, install the transducer at a shipyard.




Fig. 5.5.9 Transducer TDM-052A/062A/083 installation diagram 5

No.	Name	Material	Qty	Remarks
[1]	Transducer unit (with bottom plate)		1	
[2]	Cable gland (CG-1)	SS400	1	
[3]	Tank	SS400	1	By shipyard
[4]	Mounting bolts	SUS304	4	




Fig. 5.5.10 Transducer TDM-052A/062A/083 installation diagram 6

Installation of TDM-031D / 071 / 091D

1) In the case of steel boat

With reference to the figures below, install the transducer at a shipyard.





Fig. 5.5.11 Transducer TDM-031D/071/091D installation diagram 1

No.	Name	Material	Qty	Remarks
[1]	Transducer unit (with bottom plate)		1	
[2]	Cable gland (CG-1)	SS400	1	
[3]	Tank	SS400	1	By shipyard
[4]	Mounting bolts	SUS304	4	



Unit: mm

Fig. 5.5.12 Transducer TDM-031D/071/091D installation diagram 2

Transducer installation (For Anti-resonance)

- Caution:**
1. Plumbing pipe and welded plate or rod in dotted lines shall be provided by the shipyard after specifying the details.
 2. Preferably larger amount of protruding could produce better performance because it is hard to be influenced by bubble.

2) In the case of wooden and FRP boat

With reference to the figures below, install the transducer at a shipyard.




Fig. 5.5.13 Transducer TDM-031D/071/091D installation diagram

No.	Name	Material	Qty	Remarks
[1]	Transducer unit (with bottom plate)		1	
[2]	Cable gland (CG-1)	SS400	1	
[3]	Tank	SS400	1	By shipyard
[4]	Mounting bolts	SUS304	4	




Fig. 5.5.14 Transducer TDM-031D/071/091D installation diagram 4

Outline dimensions and specifications of transducers

- Outline dimensions and specifications of transducers (TD-501C)




Fig. 5.5.15 Outline dimensions of a transducer (TD-501C)

Specifications of transducers (TD-501C)

Cable length	10 m (393 45/64)
Weight	4.2kg (9.3lb)
Material	Rubber mold (Polyurethane)

• Outline dimensions and specifications of transducers (TD-501T-3B)

Unit: mm (inch)




Fig. 5.5.16 Outline dimensions of a transducer (TD-501T-3B)

Specifications of transducer (TD-501T-3B)

Cable length	9 m ($354 \frac{5}{16}$)
Weight	3.6kg (7.95lb)
Material	Bronze

• Outline dimensions and specifications of transducers
(TD-284A/TD-404T/ TD-504T/TD-504F)

Unit: mm (inch)




Fig. 5.5.17 Outline dimensions of a transducer (TD-284A/TD-404T/TD-504T/ TD-504F)

Specifications of transducers (TD-284A/TD-404T/TD-504T/TD-504F)

Cable length	15 m (590 35/64)
Weight	11.0kg (24.3lb)
Material	Rubber mold (Polyurethane)

• Outline dimensions and specifications of transducers (TD-754)




Fig. 5.5.18 Outline dimensions of a transducer (TD-754)

Specifications of transducer (TD-754)

Cable length	15 m (590 35/64)
Weight	6.5kg (14.3lb)
Material:	Rubber mold (Polyurethane)

• Outline dimensions and specifications of transducers (150kHz 120φx1)




Fig. 5.5.19 Outline dimensions of a transducer (150kHz 120φx1)

Specifications of transducer (150kHz 120φx1)

Cable length	12 m (472 7/16in)
Weight	3.9kg (8.6lb)
Material	Rubber mold (Polyurethane)

• Outline dimensions and specifications of transducers (NGM100-200-12L)




Fig. 5.5.20 Outline dimensions of a transducer (NGM100-200-12L)

Specifications of transducer (NGM100-200-12L)

Cable length	12 m (472 7/16in)
Weight	3.2kg (7.1lb)
Material	Rubber mold (Polyurethane)

• Outline dimensions and specifications of transducers (TDM-052A/062A/083)




Fig. 5.5.21 Outline dimensions of a transducer (TDM-052A/062A/083)

Specifications of transducers (TDM-052A/062A/083)

Cable length		15M (590 35/64in)
Weight	TDM-052A	11.0kg (24.5lb)
	TDM-062A	11.4kg (25.2lb)
	TDM-083	13.9kg (30.7lb)
Material		Polyurethane mold



Caution: 1. Four holes on the upper surface of transducer is for supplemental fixing only. Do not install the transducer only by these holes. These holes are not strong enough to sustain the weight of transducer. Transducer might come off when using it as a hole of the main that installs transducer.

2. Always operate the transducer in water. Operating in air will allow the transducer to overheat resulting in failure.




Fig. 5.5.22 Caution concerning equipment of transducer (TDM-052A/062A/083)

• Outline dimensions and specifications of transducers (TDM-031D/071/091D)




Fig. 5.5.23 Caution concerning equipment of transducer (TDM-031D/071/091D)

Specifications of transducers (TDM-031D/071/091D)

Cable length		15M (590 35/64in)
Weight	TDM-031D	3.9kg (8.6lb)
	TDM-071	4.4kg (9.7lb)
	TDM-091D	4.3kg (9.5lb)
Material		Polyurethane mold

• Outline dimensions and specifications of transducers (TD340-K)

Unit: mm (inch)




Fig. 5.5.24 Caution concerning equipment of transducer (TD340-K)

Specifications of transducers (TD340-K)

Cable length	11.7M (460 5/8in)
Weight	3.3kg (7.3lb)
Material	ABS Resin and Polyurethane

• Outline dimensions and specifications of transducers (TD360-K)

Unit: mm (inch)




Fig. 5.5.25 Caution concerning equipment of transducer (TD360-K)

Specifications of transducers (TD360-K)

Cable length	14.7M (578 47/64in)
Weight	6.4kg (14.1lb)
Material	ABS Resin and Polyurethane

• Outline dimensions and specifications of transducers (TD361-K)

Unit: mm (inch)




Fig. 5.5.26 Caution concerning equipment of transducer (TD361-K)

Specifications of transducers (TD361-K)

Cable length	14.7M (578 47/64in)
Weight	5.6kg (12.3lb)
Material	ABS Resin and Polyurethane

- **Outline dimensions and specifications of transducers (TD380-K)**

Unit: mm (inch)




Fig. 5.5.27 Caution concerning equipment of transducer (TD380-K)

Specifications of transducers (TD380-K)

Cable length	14.7M (578 47/64in)
Weight	9.3kg (20.5lb)
Material	ABS Resin and Polyurethane

5.6 Connection of Transducer

There are transducer cables: one with an 8-core waterproof connector on one side, and the other without processing.

Transducer connection to the connectors of Display unit

The connector to be connected differs depending on the TD. TDs with 8-core waterproof connectors (TD-501C, TD-501T-3B, TDM-031D, TDM-071, TDM-091D) and "Others 1kW" TDs connect to the J6 connector. Connect except for above TDs to the J7 connector.


Transducer connection method

- 1) In the case of one with an 8-core waterproof connector on one side
Connect to the J6 connector on the back of the display unit.
- 2) In the case of using CW-840-0.3M (1kW transducer)
The user must have the cable, CW-840-0.3M for the transducer.
Solder the transducer to CW-840-0.3M while referring to the table on connecting transducers.
After soldering is completed, please be sure to add water-resistance and insulation by applying electrical tape (or other such tape) onto the soldered part of the cable.
(Connect to the J6 connector.)

Transducer Connection Table

Transducer Cable		Transducer
2 lead shield wire number	2 lead shield wire color	TD-501C
③	orange	black
④	shield	shield
⑤	white	white

CW-840-0.3M



Caution: Wind the insulation tape around the un-used lead wire for core-wires not to contact each other.

Fig. 5.6.1 CW-840-0.5M transducer connection diagram

3) In the case of using CW-836-3M (2 to 3kW transducer)

Refer to the connection table of transducers, solder CW-836-3M to the transducer. After soldering is completed, be sure to provide the connected part with water resistance and insulation using self-adhesive tape, etc.

Connect the CW-836-3M that has been processed to the J7 connector.



Fig. 5.6.2 CW-836-3M transducer connection diagram

Connection table of transducer

Connectors to be connected		CW-836-3M		Note
No.	J7	Color of cable	Name of signal	-
3	GND	Shield*	GND	High freq / low freq common
5	TD 2L (Low frequency transducer)	Black	TD2L	
2	TD 1L (Low frequency transducer)	White	TD1L	High frequency
4	TD 2H (High frequency transducer)	Green	TD2H	
1	TD 1H (High frequency transducer)	Red	TD1H	

* For the transducer shield connected to the CW-836-3M shield, connect the shield wires of the outer layer shield, low frequency shield, high frequency shield, etc. together.



Caution: Wind the insulation tape around the un-used lead wire for core-wires not to contact each other.

4) In the case of using JB-34 and CW-844-3M (option) (2kW to 3kW transducer)

● **For High frequency transducer**

Connect the cable connected to this unit and JB-34.

⚠ Caution: Wind the insulation tape around the un-used lead wire for core-wires not to contact each other.

Connection example of transducer, water temperature sensor, ship speed sensor.




Fig. 5.6.3 JB-34 connection diagram 1

JB-34 connection table 1 (High frequency transducer)

Display unit		Cable	JB-34	Transducer, Sensor
Connector		CW-844-3M of cable color	Pin No.	Signal name at connection to:
J6	4	Shield	10	Shield
	8	Black	11	Speed sensor power (-)
	7	Red	13	Water temperature sensor input
	6	Green	14	Water temperature sensor power
	2	White	15	Speed sensor power (+)
	1	Blue	16	Speed sensor input
Connector		CW-836-3M cable color	Pin No.	Signal name at connection to:
J7	1	Red	2	TD1H (High frequency transducer)
	3	Shield	3	GND
	4	Green	4	TD2H (High frequency transducer)

⚠ Caution: When the Water temperature sensor/Speed sensor is not connected to JB-34, CW-844-3M is not used.

● **Low frequency transducer**

Connect the cable connected to this unit and JB-34.



Caution: Wind the insulation tape around the un-used lead wire for core-wires not to contact each other.

Connection example of transducer, water temperature sensor, ship speed sensor.




Fig. 5.6.4 JB-34 connection diagram 2

JB-34 connection table 2 (Low frequency transducer)

Display unit		Cable	JB-34	Transducer, Sensor
Connector		CW-844-3M of cable color	Pin No.	Signal name at connection to:
J6	4	Shield	10	Shield
	8	Black	11	Speed sensor power (-)
	7	Red	13	Water temperature sensor input
	6	Green	14	Water temperature sensor power
	2	White	15	Speed sensor power (+)
	1	Blue	16	Speed sensor input
Connector		CW-836-3M of cable color	Pin No.	Signal name at connection to:
J7	2	White	2	TD1L (Low frequency transducer)
	3	Shield	3	GND
	5	Black	4	TD2L (Low frequency transducer)



Caution: When the Water temperature sensor/Speed sensor is not connected to JB-34, CW-844-3M is not used.

5) In the case of connecting two transducers with JB-34 (2kW to 3kW transducer)

● **Connection example of TD-284A and TD-754.**




Fig. 5.6.5 JB-34 connection diagram 3

JB-34 connection table 3 (Connection of TD-284A and TD-754)

Display unit		Cable	JB-34	Transducer	
Connector		CW-836-3M of cable color	Pin No.	TD-284A of cable color	Signal name at connection to:
J7	2	White	8	White	TD1L (Low frequency transducer)
	3	Shield	9	Shield	GND
	5	Black	10	Black	TD2L (Low frequency transducer)
Connector		CW-844-3M of cable color	Pin No.	TD-754 of cable color	Signal name at connection to:
J7	1	Red	2	White	TD1H (High frequency transducer)
	3	Shield	3	Shield	GND
	4	Green	4	Black	TD2H (High frequency transducer)

XID-adaptive TD connection method

To use the XID-adaptive TD, you must connect an XID signal. When using an XID-adaptive TD, the ship speed sensor cannot be used.

1) In the case of using CW-844-3M and CW-836-3M. (TDM-052A/062A/083)

Refer to the TD connection table, solder CW-836-3M and CW-844-3M to the transducer. After soldering is completed, be sure to provide the connected part with water resistance and insulation using self-adhesive tape, etc.

Connect CW-844-3M after the processing to J6 connector of Display unit.
Connect CW-836-3M after the processing to J7 connector of Display unit.




Fig. 5.6.6 XID-adaptive TD cable details 1




Fig. 5.6.7 XID-adaptive TD cable connection diagram 1

XID-adaptive TD connection table 1

Display unit			Cable	Transducer, Water temp. sensor	
Connector	No	Name of signal	CW-844-3M Color of cable	Color of cable	Name of signal
J6	4	Transducer shield	Shield *	Violet Shield	XID GND Shield (insize)
	6	Water temperature sensor power	Green	White	Water temp. sensor power
	7	Water temperature sensor input	Red	Brown	Water temp. sensor input
	8	XID data	Black	Orange	XID data
	1	Speed sensor input	Blue	-	-
	2	Speed sensor power (+)	White	-	-
	3	Transducer input output	Orange***	-	-
	5	Transducer input output	-	-	-
Connector	No	Name of signal	CW-836-3M Color of cable	Color of cable	Name of signal
J7	1	TD1H (High frequency transducer)	Red	Blue	TD1H (High frequency transducer)
	2	TD1L (Low frequency transducer)	White	Blue / White (Yellow)**	TD1L (Low frequency transducer)
	3	Shield	Shield *	Shield	Shield (Low frequency)
				Shield	Shield (outsize)
				Shield	Shield (High frequency)
	4	TD2H (High frequency transducer)	Green	Black	TD2H (High frequency transducer)
	5	TD2L (Low frequency transducer)	Black	Black / White (Black)**	TD2L (Low frequency transducer)

* Connect multiple wires together into one bundle.

** For low frequency cable of transducer, there are two combinations of (Black : Yellow) and (Black/White : Blue/White). Connect them with the corresponding cable of CW-836-3M and solder them.

*** Do not connect anything to the orange cable of CW-844-3M.

2) In the case of using JB-34 and CW-844-3M (option). (TDM-052A/062A/083)

Connect the JB-34 and the XID-adaptive TD as shown in the diagram below.

Connect CW-844-3M and CW-836-3M to the display unit.




Fig. 5.6.8 JB-34 XID-adaptive TD connection diagram

JB-34 XID-adaptive TD connection table 2

Display unit			Cable	JB-34	Transducer, Water temperature sensor	
Connector	No	Name of signal	CW-844-3M Color	Pin No.	Color of cable	Name of signal
J6	4	Shield	Shield*	10	Violet	XID GND
					Shield	Shield (Inside)
	8	XID data	Blak	11	Orange	XID data
	7	Water temperature sensor input	Red	13	Brown	Water temperature sensor input
	6	Water temperature sensor power	Green	14	White	Water temperature sensor power
	2	Speed sensor power (+)	White	-	-	-
	1	Speed sensor input	Blue	-	-	-
	3	Transducer input output	Orange***	-	-	-
	5	Transducer input output	-	-	-	-
Connector	No	Name of signal	CW-836-3M Color	Pin No.	Color of cable	Name of signal
J7	1	TD1H (High frequency transducer)	Red	1	Blue	TD1H (High frequency transducer)
	4	TD2H (High frequency transducer)	Green	2	Black	TD2H (High frequency transducer)
	3	Shield	Shield	3	Shield	Shield
	2	TD1L (Low frequency transducer)	White	5	Blue/White (Yellow)**	TD1L (Low frequency transducer)
	5	TD2L (Low frequency transducer)	Black	6	Black/White (Black)**	TD2L (Low frequency transducer)
	3	Shield	Shield*	7	Shield	Shield
					Shield	Shield (Outside)

* Connect multiple wires together into one bundle.

**For low frequency cable of transducer, there are two combinations of (Black : Yellow) and (Black/White : Blue/White). Connect them with the corresponding cable of CW-836-3M and solder them.

*** Do not connect anything to the orange cable of CW-844-3M.

3) In the case of with 8-core waterproof connector (TDM-031D/071/091D)

Connect to J6 connector of Display unit.

XID-adaptive TD connection table 3 (8-core waterproof connector)

Display unit			Transducer, Water temperature sensor	
Connector	No	Name of signal	Color of cable	Name of signal
J6	1	Speed sensor input	-	-
	2	Speed sensor power (+)	-	-
	3	Transducer input output	Blue	Transducer
	4	Transducer shield*	Shield	Shield
			Shield	Shield (Inside)
			Shield	Shield (Outside)
	5	Transducer input output	Black	Transducer
	6	Water temperature sensor power	Brown	Water temperature sensor power
	7	Water temperature sensor input	White	Water temperature sensor input
	8	XID data	Orange	XID data

* Connect multiple wires together into one bundle.

4) In the case of using CW-840-0.3M. (TDM-031D/071/091D)

Refer to the TD connection table, solder CW-840-0.3M to the transducer. After soldering is completed, be sure to provide the connected part with water resistance and insulation using self-adhesive tape, etc.

Connect CW-840-0.3M after the processing to J6 connector of Display unit.




Fig. 5.6.9 XID-adaptive TD cable connection diagram 2




Fig. 5.6.10 CW-840-0.3M transducer connection diagram 2

XID-adaptive TD connection table 4 (CW-840-0.3M)

Display unit			Cable	Transducer, Water temperature sensor	
Connector	No	Name of signal	Color	Color	Name of signal
J6	1	Speed sensor input	Blue	-	unused**
	2	Speed sensor power (+)	Violet	-	unused**
	3	Transducer input output	Orange	Blue	Transducer
	4	Transducer shield	Shield*	Shield	Shield
				Shield	Shield (Inside)
				Shield	Shield (Outside)
	5	Transducer input output	White	Black	Transducer
	6	Water temperature sensor power	Green	Red	Water temperature sensor power
	7	Water temperature sensor input	Red	White	Water temperature sensor input
	8	XID data	Black	Orange	XID data

* Connect multiple wires together into one bundle.

**Waterproof and insulate unused cable with self-adhesive tape, etc.

TD340-K/360-K/361-K/380-K connection method

1) In the case of using CW-836-3M. (TD340-K/360-K/361-K/380-K)

Refer to the TD connection table, solder CW-836-3M to the transducer. After soldering is completed, be sure to provide the connected part with water resistance and insulation using self-adhesive tape, etc.

Connect CW-836-3M after the processing to J7 connector of Display unit.




Fig. 5.6.11 TD340-K/360-K/361-K/380-K transducer cable connection diagram

TD340-K/360-K/361-K/380-K transducer connection table 1

Display unit			CW-836-3M	Transducer	
Connector	No	Name of signal	Color	Color	Name of signal
J7	1	TD1H (High frequency transducer)	Red	Red	TD1H (High frequency transducer)
	2	TD1L (Low frequency transducer)	White	White	TD1L (Low frequency transducer)
	3	Shield	Shield	Shield	Shield
	4	TD2H (High frequency transducer)	Green	Green	TD2H (High frequency transducer)
	5	TD2L (Low frequency transducer)	Black	Black	TD2L (Low frequency transducer)

2) In the case of using JB-34 and CW-844-3M (option). (TD340-K/360-K/361-K/380-K)

Connect the cable connected to this unit and JB-34.

Caution: Wind the insulation tape around the un-used lead wire for core-wires not to contact each other.

Connection example of transducer, water temperature sensor, ship speed sensor.




Fig. 5.6.12 JB-34 TD340-K/360-K/361-K/380-K transducer connection diagram

JB-34 TD340-K/360-K/361-K/380-K transducer connection table 2

Display unit			Cable	JB-34	Transducer, Water temperature sensor	
Connector	No	Name of signal	CW-844-3M Color	Pin No.	Color cable	Name of signal
J6	4	Shield	Shield*	10	-	Shield
	8	Speed sensor power (-)	Black	11	-	Speed sensor power (-)
	7	Water temperature sensor input	Red	13	-	Water temperature sensor input
	6	Water temperature sensor power	Green	14	-	Water temperature sensor power
	2	Speed sensor power (+)	White	15	-	Speed sensor power (+)
	1	Speed sensor input	Blue	16	-	Speed sensor input
Connector	No	Name of signal	CW-836-3M Color	Pin No.	Color cable	Name of signal
J7	1	TD1H (High frequency transducer)	Red	1	Red	TD1H (High frequency transducer)
	4	TD2H (High frequency transducer)	Green	2	Green	TD2H (High frequency transducer)
	2	TD1L (Low frequency transducer)	White	4	White	TD1L (Low frequency transducer)
	5	TD2L (Low frequency transducer)	Black	5	Black	TD2L (Low frequency transducer)
	3	Shield	Shield	6	Shield	Shield



Caution: When the Water temperature sensor / Speed sensor is not connected to JB-34, CW-844-3M is not used.

- This page intentionally left blank.-

Chapter 6 Table Attached

6.1 Menu List

The factory set value is shown by the bold and underline.

[DISP] key

Disp NAV1, Normal (H), Zoom (H), **Dual freq**, Zoom (L), Normal (L), NAV2

[▲RANGE▼] key

RANGE **Auto range**, 5.0, 10.0, 20.0, 50.0, 100, 160, 300, 500, Auto shift

[GAIN(HF)], [GAIN(LF)]

Gain 0.0 to 10.0 (H): **6.0**, (L): **6.0**

TVG STC depth H, STC depth L, **High Sensitivity**, Based on Seabed

[BRILL] key

LCD brill 1 to 10: **10**

Panel brill 1 to 10: **10**

[EVENT] key

Store pos, Store image, Fishing hot spot

[F1] key

Image speed, IR, Color rejection, Noise rejection, Shift, Zoom range, Zoom start, A scope, White line, Background color, Disp width, NAV start, NAV1, NAV2, Image swap, Image recall, User set, Ext synchronized

[F2] key

Image speed, IR, Color rejection, Noise rejection, **Shift**, Zoom range, Zoom start, A scope, White line, Background color, Disp width, NAV start, NAV1, NAV2, Image swap, Image recall, User set, Ext synchronized

[MENU] key

Adjust

Image speed (Speed1, Speed2, Speed3, Speed4, Stop, **Speed5 (1/1)**, Speed6, Speed7, Speed8, Speed9)

IR (**OFF**, Weak, Strong)

Color rejection (0 to 50 %: **0%**)

Noise rejection (0 to 10: **0**)

TX power (20, 30, 40, 50, 60, 70, 80, 90, 100, **Auto**)

Gain (TD) (-50 to 50)

Pulse width (Super short, Short, **Middle**, Long)

Band width (Super narrow, Narrow, **Middle**)

D.Range (12dB to 30dB: **24dB**)

Inner-hull : No
H: **0**, L: **0**

Inner-hull : Yes
H: **15**, L: **30**

D.range

Shift step (**1m**, 10m, 1/8, 1/4)

Zoom type (**Bottom**, Bottom Discrimination, Zoom, Bottom Zoom, Bottom Follow Zoom)

Zoom range (2.5 to 200 m: **10.0 m**)

Zoom start (0 to 2000 m: **0m**)

Disp width (Left2, Left1, **Center**, Right1, Right2)

Range preset

Inner-hull : No
Range 1 (2.5 to 2000 m: **5.0**)
Range 2 (2.5 to 2000 m: **10.0**)
Range 3 (2.5 to 2000 m: **20.0**)
Range 4 (2.5 to 2000 m: **50.0**)
Range 5 (2.5 to 2000 m: **100**)
Range 6 (2.5 to 2000 m: **160**)
Range 7 (2.5 to 2000 m: **300**)
Range 8 (2.5 to 2000 m: **500**)

Inner-hull : Yes
Range 1 (2.5 to 2000 m: **5.0**)
Range 2 (2.5 to 2000 m: **10.0**)
Range 3 (2.5 to 2000 m: **20.0**)
Range 4 (2.5 to 2000 m: **50.0**)
Range 5 (2.5 to 2000 m: **80**)
Range 6 (2.5 to 2000 m: **100**)
Range 7 (2.5 to 2000 m: **160**)
Range 8 (2.5 to 2000 m: **200**)

Display1

A scope (**OFF**, ON)

White line (**OFF**, 1, 2, 3, 4, 5, Auto)

Background color (Pale blue, Marine blue, Blue, **Dark blue**, Black, Darkkhaki, Mediumseagreen, Light grey, White, Night mode)

Color tone (Monochrome, 8 color, 16 color, **64 color**)

Depth value (OFF, Small, Middle, **Large**)

Unit display (**OFF**, ON)

Water temp graph (**OFF**, ON)

Fish symbol (**OFF**, Symbol 1 to Symbol 10)

Symbol info (OFF, Depth, **Size**, Bottom↔Fish)

Display2

Detection area (OFF, **ON**)

Scale display (OFF, One, **All**)

Scale (Small, Middle, **Large**)

Image direction (**←|←**, **→|→**, **←|→**)

Bottom detection (**Auto**, High frequency, Low frequency)


Color table1 (Header information, Header BG color, VRM, Depth, Scale, Scale line, Detection area H, Detection area L)

Color table2 (Symbol info, Menu BG color, Big fish color, Bottom color)


Scale type (**0**, 1)

Big fish (20 to 90: **50**)

Bottom Hardness (**OFF**, ON)



B	Freq	Freq select (H) (24.0 to 210.0kHz: Table 6-1)
		Freq select (L) (24.0 to 210.0kHz: Table 6-1)
		Power freq adj H (100.0 to 130.0 : 118.5)
		Power freq adj L (100.0 to 130.0 : 118.5)
		Freq display (OFF , ON)
	In out	Buzzer setting (OFF, ON)
		Temp source (ST/TC , NMEA)
		Speed source (InsideSensor, NMEA)
		Baud rate (4800 , 9600, 19200, 38400)
		NMEA monitor (OFF , ON)
		NMEA output data (ON : DBT, DPT, TLL OFF : GGA, MTW, VHW, VTG, ZDA)
		NMEA output data (ON : None OFF : GLL, HDT, MWV, RMC, Olex, Nobeltec, PKODS,4)
		Ext synchronized (OFF , ┐ , └)
		Unreceived sync (Stop , Auto)
	Correct	Draft set (- 10.0 to 10.0 m: 0.0 m)
		Sonic speed (Seawater , Freshwater)
		Water temp (- 10.0 to 10.0 °C: 0.0 °C)
		Boat speed (- 50.0 to 50.0 %: 0%)
		Beam angle H (1 to 120: Table 6-1)
		Beam angle L (1 to 120: Table 6-1)
		Size adjust (1 to 10: 6)
		Detect adjust f (1 to 6: 4)
		Bubble (OFF , Weak, Strong)
		Bubble time set (OFF, 1 to 10min: 1min)
	Setting	Language (English, Japanese, Greek, Spanish, Italian, French, Chinese 1, Chinese 2, Danish, Korean, Thai, Vietnamese)
		Range&Speed unit (NM, kn , km, km/h)
		Depth unit (m , fm, l.fm, ft)
		Temperature unit (°C , °F)
		Localtime offset (- 11.0 to 14.0: 0.0)
		GPS select (Others , KODEN GPS)
		GPS initialize (No , Yes)
		Bottom start (0.0 to 20.0: 1.5)
		Past image (OFF, ON)
C		

**Table 6-1 Factory settings for Freq select and Beam angle**

TD select	Freq select H / L	Beam angle H / L	TD select	Freq select H / L	Beam angle H / L
TD-501C	200/50kHz	17/58°	Others 1kW	200/50kHz	10/20°
TD-501T-3B	200/50kHz	5/20°	Others 3kW	200/50kHz	10/20°
TDM-031D	200/50kHz	9/27°	TDM-052A	130/38kHz	11/20°
TD-284A	28kHz	30°	TDM-062A	80/38kHz	18/20°
TD-404T	40kHz	16°	TDM-071	65/35kHz	15/27°
TD-504F	50kHz	14°	TDM-083	130/28kHz	11/23°
TD-504T	50kHz	14°	TDM-091D	200/42kHz	9/35°
TD-754	75kHz	14°	TD340-K	130/38kHz	13/42°
150kHz 120φx1	150kHz	7°	TD360-K/361-K	130/38kHz	13/31°
NGM100-200-12L	200kHz	6°	TD380-K	130/38kHz	13/23°


6.2 Specification

Item	Content
Model	CVS-1420
Output power (RMS)	1kW to 3kW
Transducer (Output frequency)	TD-501C (50/200 kHz), TD-501T-3B (50/200 kHz), TDM-031D (50/200kHz), TD-284A (28 kHz), TD-404T (40 kHz), TD-504F (50 kHz), TD-504T (50 kHz), TD-754 (75 kHz), 150kHz 120φx1 (150kHz), NGM100-200-12L (200kHz), TDM-052A (38-75/130-210kHz), TDM-062A (38-75/80-130kHz), TDM-071 (35-65kHz), TDM-083 (28-60/130-210kHz), TDM-091D(42-65/130-210kHz), TD340-K (38-70/130-220kHz), TD360-K/361-K (38-70/130-220kHz), TD380-K (38-70/130-220kHz)
Selectable frequency range	24kHz to 220kHz (0.1kHz step)
Output method	Single or Alternate
Pulse width	50 μs to 3.0 ms
Display size and type	10.4 inch color LCD
Display resolution	640 x 480 pixels (VGA)
Basic range	2.5 to 2000 (m), 10 to 6000 (ft), 2.5 to 1100 (fm / I. fm) (8 ranges can be set to users choice)
Zoom range	2.5 to 200 (m), 10 to 650 (ft), 2.5 to 150 (fm / I. fm)
Range unit	m, ft, fm, I.fm
Shift	Max 2000 (m), 6000 (ft), 1100 (fm / I. fm)
Shift step	1m, 10m, 1/8, 1/4
Presentation modes	High frequency, Low frequency, Dual frequency, Zoom image (Bottom lock, Bottom discrimination, Bottom zoom, Zoom, Bottom follow zoom), Nav mode, Vertical split, Horizontal split A-scope can be displayed at all above modes
Presentation colors	64 colors, 16 colors, 8 colors, Monochrome
Back ground colors	Marine blue, Blue, Black, White, Nighttime color, Other 5 colors
Alarms	Bottom, Fish, Temperature*, Speed**, Arrival**, XTE**
Image speed	9 steps & stop
Functions	Interference rejection, Color rejection, VRM, Noise reduction, White line, Draft correct, Water temperature correct, Boat speed correct, Store image (10 images), Fishing Hot Spot, Event memory, Simple plotter, Panel illumination, Power reduction, External trigger, Detection area display, Fish information, XID, Bottom Hardness display
Auto functions	Range, Shift, TVG, TX Power, White Line
Function registration	Image speed, A scope, Shift, Interference rejection, Color rejection, Noise rejection, Zoom range, Zoom start, White line, Background color etc
Language	English, Japanese, Greek, Spanish, Italian, French, Korean, Thai, Chinese1, Chinese2, Danish, Vietnamese
Input data format and sentences	NMEA0183 Ver.1.5 / 2.0 / 3.0 GGA, GLL, HDT, MTW, MWV, RMC, VHW, VTG, ZDA
Output data format and sentences	NMEA0183 Ver.2.0 / 3.0 (DBT : Ver.1.5) DBT, DPT, GGA, GLL, HDT, MTW, MWV, RMC, TLL, VHW, VTG, ZDA, Olex, Nobeltec, PKODS, 4
NMEA input / output port(s)	Total 1 : input and output
Power supply	10.8 to 31.2 V DC
Power consumption	50 W or less (24V DC)
Environmental	
Operating temperature	- 15 °C to + 55 °C
Water protection	IPX5
Store temperature	- 30 °C to + 70 °C
Upper limit of humidity	93 % ± 3 % (At + 40 °C)
Dimension of equipment (without knob & pedestal)	320.0 × 320.0 × 138 mm
Dimension of equipment (with knob & pedestal)	330.2 × 364.0 × 174.5 mm
Weight	7.8 kg

* Requires data from Temp sensor

** Requires data from GPS sensor

6.3 Dimensions





Koden Electronics Co., Ltd.

Tamagawa Office:

2-13-24 Tamagawa, Ota-ku, Tokyo, 146-0095 Japan

Tel: +81-3-3756-6501 Fax: +81-3-3756-6509

Uenohara Office:

5278 Uenohara, Uenohara-shi, Yamanashi, 409-0112 Japan

Tel: +81-554-20-5860 Fax: +81-554-20-5875

www.koden-electronics.co.jp