SC

Track[On]	Track color	Rotation	Measurement
Measurement	Day	Forward	Backward

(1) Press **SC** to show the Quick Menu.

(2) Use **(arrows)** to select the operation.

RANGE

▲ RANGE ▼

(1) Press "RANGE Up" ▲ to zoom-in and show the detailed chart.

(2) Press "RANGE Down" ▼ to zoom-out and show the general chart.

NAVI

Navigation

Waypoint

ID 00000
Name W00000

NAVI   Cancel

(1) Press **NAVI** to call out navigation menu.

(2) Can choose waypoint navigation or route forward/reverse navigation.

(3) To cancel the current navigation, press **NAVI** again and select Cancel.

BRILL

Brightness/Volume

Brightness:80%

Key Brightness:80%

Volume:60%

(1) Power on: Press **BRILL** until the Opening Display appears.

(2) Power off: Press **BRILL** for 3 seconds.

(3) Brightness/Volume: Press **BRILL** and adjust the setting values of brightness and volume by **(arrows)** .

CURSOR

Press **CURSOR** to show/hide the cursor.

EVENT

Press **EVENT** to add marker.

QUIT

Press **QUIT** to quit current operating state.

DISP

DISP Long press

- Full Screen Map
- Compass
- NAV

(1) Use **(arrows)** to select the Display modes.

(2) Press **QUIT** .

(3) Press **DISP** to rotate the selected Display modes.

POB

Press **POB** to record the current position.

MENU

Function Menu

● While Cursor is on, press MENU to show the Function Menu.

> Full Screen
> Custom Panel
> Add Waypoint
> Add Beacon
> Add Marker
> Add Route
> Add Drawing

Add Waypoint

Use to select "Add Waypoint ".

After selection, use to move cursor and add Waypoint.

The rule of "Add Beacon"or "Add Marker" is the same as "Add Waypoint ".

Add Route

Use to select "Add Route ".

After selection, use to move cursor and add Waypoint for Route.

Press QUIT to save Route and input the Route name.

Note that a Route should include at least 2 Waypoints.

Add Drawing

Use to select "Add Drawing".

After selection, use to move cursor and add Nodes for Drawing.

Press QUIT to save Drawing .There will be a message to prompt to loop the drawing line or not. Then input the Drawing ID, Color and Comment.

MENU

Main Menu

● Press MENU 2 times to show the Main Menu.

Use to select Main Menu.

MENU 2 times

Alarm

Use to select "Alarm".

Choose the Alarm you want to turn on.

When Alarm happens, the alarm information appears and buzzer beeps untill you press QUIT to quit the alarm.

FUNC

Press FUNC to switch the Main Menu and System Menu.

0093107004-00